

To Set Hand Shower Settings

Turn Dial Lever (Fig. 5) to select desired water pattern. Choose from 4 full and 2 combination settings.

To Set Hand Shower Angle


Loosen Ball Joint Nut and Rotate Holder to desired position, then tighten Ball Joint Nut.

To Save Water while Lathering or Shampooing

To reduce water flow, turn Dial Lever to Pause mode.


Pause mode does not shut off water completely? It is designed this way for your protection.

For safety (to prevent pressure buildup), Pause mode has water dripping instead of complete shut-off (Fig. 6). After use, DO NOT leave hand shower set to Pause mode.



Extra-low Water Pressure? You can remove Flow Regulator.

As mandated by U.S. federal law, this hand shower is equipped with water flow regulator that limits maximum water flow to 2.5 gallons (9.5 liters) per minute at 80 psi water pressure. In areas with extremely low water pressure causing the shower water flow to be unsatisfactory, the flow regulator may be removed to improve the water flow in the shower head.



Using screwdriver point or long nose pliers, pull out Water Regulator located inside Shower Handle (fig. 7).

Cleaning Instructions

To maintain proper working condition, cleaning is required when mineral deposits appear on jet tips. Clean flexible nozzles by rubbing with a finger or soft bristled toothbrush, or soaking them in 50/50 solution of white vinegar and water. Do not clean or rinse any part with harsh chemicals, heavy-duty cleaners or abrasives. This may damage parts or finish and may void warranty.

If you have installation problem or missing parts, please DO NOT return this product before calling us first. We can help on the phone or by quickly sending needed parts.

For Questions/Part Replacement Call Toll Free

1-888-869-4010

Monday - Friday 9:00 AM - 4:00 PM Eastern Time

www.ipshowers.com Item 3317

LIMITED LIFETIME WARRANTY

Interlink will repair or replace any of this product's parts that exhibit defects in workmanship or materials for above stated period from date of purchase. If malfunction occurs, send only defective part(s) with proof of purchase to Customer Service Department at the address listed below. This warranty does not cover product purchased from unauthorized distributors, malfunction or damage due to accident, misuse, use of harsh chemicals or failure to follow any included written instructions. This warranty gives you specific legal rights. You may also have other rights that vary where you reside.