


DHW093LN105A

Assembly Instructions



Attention for assembly

1. Prepare a ladder to assemble this product.

2. At least 2 adults are required for assembly.

3. Read the instruction carefully and completely before assembling the product.

4. Follow the instructions step by step. Any wrong operation might damage the product, which will not be considered as quality defect of product itself. Any return caused by this reason will not be accepted.

5. Place product on soft floor (carpet, cardboard, wood) for assembly to prevent scratching or damage, never on concrete, sand or slate floor.

6. Verify all components and hardware are included according to the part list before start assembling. In case of missing of any part, stop assembling and contact us right away.

7. Electrical tools (not included) help assembly yet do not over drive the screws, bolts, nuts, etc.

8. Do not fasten screws, bolts, nuts tightly until the whole product is assembled completely in place. In case you have difficulty to put the parts together, try to loosen the fastened screws, bolts, nuts, which might solve the problem.

9. Follow the manpower request for assembly. Shortage of manpower might cause unsuccessful assembly or personal injury.

10. Do not use the product until all the components, screws, bolts, nuts are fastened tightly.

11. Contact us when you have any problem regarding assembly or any product issues, we will respond as soon as possible to help you out of problem. Don't return the goods on your purchase platform right away.

Usage and Maintenance

1. Only use this product on level ground, never use it on inclined ground.

2. Do not use in bad weather, wild wind might blow out the gazebo.

3. Check regularly all components, bolts, screws, nuts to be secured firmly.

4. Clean the product by a damp cloth only.

People Required: 2








Tools Required: Included

Assembly Time: 50 minutes

Follow our assembly video



A  4PCS	B  1PC	C  1PC		
D  2PCS	E  4PCS	F  2PCS		
G  4PCS	H  4PCS	I  1PC	Y  1PC	
J  1PC	K  2PCS	L  1PC	M  4PCS	N  4PCS
O  4PCS	P  4PCS	Q  2PCS	R  1PC	S  1PC
T  M6*15 46PCS	U  M6*25 4PCS	V  M6*30 12PCS	W  14PCS	X  76PCS
①  1PC	②  1PC	③  1PC	④  1PC	⑤  8PCS
⑥  8PCS				


第6页

第3页

第4页

第5页


STEP 7



Fix the gazebo to the ground with part ⑥ when on the grass, use expansion screw ⑤ when on the cement.

STEP 1

Insert the part N, connect pole A and part O use bolt T and washer X, then put down the part N.




STEP 2

1. The other end of the part A is connected to the pole B, C, D with bolt T and washer X.


2. Assemble the part R on the rod B with bolt T and washer X.

3. Assemble the part P with pole B, C, D.



STEP 3

Using bolt V, washer X and nut W, connect bracket E with component Q; using bolt T, washer X and nut W, connect bracket E




STEP 4

1. Connect frame E and F to the top of columns C, B, and D with bolt T and washer X.

2. Install components I and Y on columns C, B, and D using parts M, bolt T, U, and washer X.


3. Assemble hook J with shelf I with bolt V and washer X.



STEP 5

1. Insert all part G, H in turn and tube K into center frame L and make sure connected firmly.

2. Connect the hook S with center frame L.



STEP 6

Connect roof frame with base frame with bolt V, washer X and nut W.

