

LP369

750 Lumen LED Lantern

3 C
Batteries
Not Included



Features

- Rugged rubber design
- BROADBEAM surface LED technology
- Rubberized metal handle
- Variable on/off brightness dial
- IPX4 waterproof rating

Product Warranty

The LP369 has a Limited 90-Day Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@simpleproducts.com

| ANSI/PLATO FL1 STANDARD | | | |
|-------------------------|--------|----------|---------------|
| MODES | LUMENS | RUN TIME | BEAM DISTANCE |
| High | 750 lm | 4h | 21m |
| Low | 30 lm | 90h | 5m |

Operation Instructions

On/Off: Turn the dial on the front of the lantern clockwise to turn the light on. Turn the dial counterclockwise completely to turn the light off. There will be an audible click when turned on or off.

Adjust Brightness: Rotate the dial clockwise to increase the brightness, and counterclockwise to decrease the brightness.



Battery Replacement

The LP369 uses 3 C batteries.

To replace the batteries, turn the base of the lantern counterclockwise to loosen it and remove it. Tip the lantern downward to slide the batteries out of the battery tubes. Insert new batteries according to the (+/-) symbols outside of the battery tubes. These symbols indicate which side of the battery should be facing up. For best results, we recommend using brand new alkaline batteries that are the same voltage and brand. Re-attach the base of the lantern by aligning the base to the lantern, pressing down lightly, and turning clockwise until tight.



While turned on, the green battery indicator lights below the dial will light up to indicate the battery percentage.

| Green LED Battery Indicators | |
|--|------|
| 100% | ●●●● |
| 75% | ●●● |
| 50% | ●● |
| 25% | ● |
| Replace batteries at 25% to avoid complete loss of usability | |



If you know it will be a while between uses, we suggest removing the batteries from the lantern and storing it in a dry, protected place.