

Window Box



Versatile Sizes for Any Space

2 FT

24" L x 10" W x 9.2" H
7 Gal Soil Capacity

3 FT

36" L x 10" W x 9.2" H
10 Gal Soil Capacity

4 FT

48" L x 10" W x 9.2" H
13.2 Gal Soil Capacity

5 FT


60" L x 10" W x 22" H
16.6 Gal Soil Capacity



PRODUCT INFORMATION

Package Content:

Inspect all the pieces to ensure you have everything.



Optional Tools (Not Provided):




Small Hand
Drill



Phillips
Screwdriver Bit



A 2 x End Cap
MC2208




B 2 x Side Panel
2FT: MC2233
3FT: MC2235
4FT: MC2237
5FT: MC2239



C 1 x Bottom Panel
2FT: MC2234
3FT: MC2236
4FT: MC2238
5FT: MC2240



D Wall Mount Brackets
MC2209
2FT: 2pcs
3FT: 2pcs
4FT: 3pcs
5FT: 4pcs



E Wall Mount Screw
2FT: 4pcs
3FT: 4pcs
4FT: 6pcs
5FT: 8pcs




STEP-BY-STEP ASSEMBLY

Read the instructions before assembly.

1 Assemble the First Side Panel

Lay the bottom panel (C) flat on your work surface. Align one side panel (B) so the grooves on the panel fit snugly onto the bottom panel's rail system.




Slide the side panel down gently until fully seated.



2 Attach the Second Side Panel

Slide the second side panel (B) onto the other side of the bottom panel (C). Check that both sides are flush and securely in place.






STEP-BY-STEP ASSEMBLY

Read the instructions before assembly.

3 Secure the Ends

Align the end cap (A) with the grooves on the side panels (B) and press firmly into place. Repeat on the other side.



The snap hooks inside the panels hold the end cap in position.

4 Prepare the Brackets for Mounting

Install wall mount brackets (D) onto a flat surface—wall, brick, or wood using proper mounting anchors and methods. If mounting over siding, use strapping. Secure using wall mount screws (E). Bracket count will vary by size. See the next step for spacing details.







STEP-BY-STEP ASSEMBLY

Read the instructions before assembly.

5 Bracket Placement Guide

Install the wall mount brackets (D) on the surface where you plan to install the window box. Ensure each bracket is vertically aligned and sits flat against the surface. Secure the wall mount brackets using the wall mount screws (E). Refer to the guide below for recommended placement.

Bracket spacing vary depending on the window box size:






STEP-BY-STEP ASSEMBLY

Read the instructions before assembly.

6 Mount the Window Box

Tilt the window box slightly upward and align it above the installed brackets. Lower it straight down so the brackets slide into the grooves on the back panel and bottom channel. Make sure it's fully seated and feels secure before letting go.



Align the groove above the bracket before lowering.

7 Bring Your Window Box to Life

Your planter is ready to use. Fill it with potting soil and add your favorite flowers, herbs, or greenery.



Expand horizons and redefine outdoor elegance



All Seasons

Endure every season with lasting strength



Sure Fit

Assembles with ease for a strong, secure, lasting hold



Modern Design

A fresh, modern look grounded in timeless charm



Warranty Plus

Backed by a 10-year warranty for peace of mind

General Planting Recommendation:

To get the most out of your planter, follow these steps:

1. Add Lightweight Filler (Optional but beneficial)
 - Start by adding a few inches of lightweight filler to the bottom of your planter. This step is optional but offers three key benefits:
 - Reduces Potting Mix Usage: Saves on the amount of potting mix needed.
 - Encourages Root Growth: Promotes faster root growth down into the troughs.
 - Lightweight Options: Use materials like mulch, wood chips, crushed water bottles, or foam packing peanuts (avoid foam peanuts if growing edible plants).
2. Fill with Potting Mix
 - Fill the planter with potting mix, leaving about an inch from the top. Avoid using regular garden soil as it compacts easily and doesn't provide adequate aeration or drainage.

Cleaning & Care Guide:

A little care goes a long way. At the start of each season, give your planter a quick rinse to clear away dust and debris. For a deeper refresh, gently clean with mild soap, water, and a soft cloth—or use a pressure washer on a low setting. Rinse thoroughly and let it dry fully. With simple upkeep, your planter will continue to bring beauty and ease to your outdoor space, season after season.

NOTE: Results vary by plant type and root depth. We hold no liability for plant growth.