



# DELTA FIREPIT




Assembly Instructions



# MF FIRE



Panel 1 short slot




Ensure panels are interlocked, touching the ground



Panel 2 short slot




Squeeze Panels 1 and 2 inwards. Slide Panel 3 into long slots of Panel 1 and 2




Slide Panel 2 short slot into Panel 1 short slot



Squeeze Panels 1 and 2 inwards. Slide Panel 3 into long slots of Panel 1 and 2



Slide Panel 2 short slot into Panel 1 short slot



Ensure all panels are interlocked together



## Cooktop Care Instructions:

If you ordered a Delta Firepit Cooktop, proper care is needed before use. Prior to its first contact with food products, the cooktop should be wiped down and burned on top of the firepit to sufficiently burn off any potential impurities. After each use, the Cooktop should be cleaned thoroughly, rubbed with food-grade oil, wiped clean (while still leaving oil residue), and stored in a dry place. The Cooktop should not be left outside. If rust accumulates on the Cooktop, steel wool can be used to remove and clean it.

Thanks for ordering a Delta Firepit!

Head over to [mffire.com/myproduct](https://mffire.com/myproduct) to register your product and submit your pictures and a review. We love seeing photos of our customers using their Delta Firepit! We often provide thank-you **gifts** to customers who leave us pictures and a review.



## FOR OUTDOOR USE ONLY

### WARNING:

1. Improper installation, adjustment, alteration service or maintenance can cause injury or property damage.
2. Read the installation, operation and maintenance instructions thoroughly before installing or servicing this equipment.
3. Failure to follow these instructions could result in fire or explosion, which could cause property damage, personal injury or death.

Save these instructions for future reference. If you are assembling this unit for someone else, give this manual to him or her to read and save for future reference.

1. This appliance is for outdoor use only, and shall NOT be used in a building, garage, or any other enclosed area.
2. Do NOT use this outdoor firepit for indoor heating. TOXIC carbon monoxide fumes can accumulate and cause asphyxiation.
3. This outdoor firepit is NOT for commercial use.
4. This outdoor firepit is NOT to be operated by children.
5. This outdoor firepit is NOT to be used in or on boats or recreational vehicles.
6. Always use in accordance with all applicable local, state and national codes. Contact your local fire department for details on outdoor burning.
7. When using this outdoor firepit, exercise the same precautions you would with any open fire.
8. The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to properly assemble or safely operate this outdoor firepit.
9. Do NOT use this outdoor firepit without reading the entire "Owner's Manual".
10. This outdoor firepit is for use with dry, seasoned hardwood. It will burn hotter, more completely and create less smoke.
11. Do NOT burn charcoal briquets, lump charcoal, manufactured logs, driftwood, trash, leaves, paper, cardboard, plywood, painted or stained or pressure treated wood. Avoid using softwoods such as pine or cedar that can throw sparks.
12. Do NOT alter this outdoor firepit in any manner.
13. Do NOT use this outdoor firepit until it is COMPLETELY assembled, and all parts are securely placed.
14. Do NOT store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.
15. Do NOT store or use an LP gas cylinder within 10 feet (3.05 m) of this outdoor firepit while it is in operation.
16. Do NOT use this outdoor firepit near automobiles, trucks, vans or recreational vehicles.
17. Do NOT use in an explosive atmosphere. Keep outdoor firepit area clear and free from combustible materials, gasoline and other flammable liquids.
18. Do NOT use this outdoor firepit under any overhead or near any unprotected combustible constructions. Avoid using near or under overhanging trees and shrubs.
19. Always use this outdoor firepit on a hard, level non-combustible surface such a concrete, rock or stone. An asphalt or blacktop surface may not be acceptable for this purpose. Do NOT use on wooden decks without proper thermal and spark protection.

20. Always empty this outdoor firepit before each use. Leave a thin layer of ash to protect the bottom.
21. Do NOT wear flammable or loose clothing when operating this outdoor fire pit.
22. Do NOT use in windy conditions.
23. Do NOT use gasoline, kerosene, diesel fuel, lighter fluid or alcohol to light or relight fires.
24. Keep all electrical cords away from a hot fire pit.
25. All surfaces of this outdoor firepit are hot when in operation. To avoid burns, do NOT touch firepit until it has completely cooled unless you are wearing protective gear (Potholders, gloves, BBQ mittens, hot pads & etc.). Never touch ashes or coals to see if they are hot.
26. Do NOT leave a lit outdoor fire pit unattended, especially around children and pets
27. Do NOT attempt to store this outdoor fire pit until all ashes and coals are completely extinguished and firepit is cool.
28. Do NOT remove ashes or coals until they are completely and fully extinguished.
29. Use heat-resistant gloves or hot pads when contacting handles.
30. Use long, sturdy fire pit tools when adding or moving logs.
31. Do NOT overload the firepit. Do not add additional firewood until the fire burns down. NOTICE: If any portion of this outdoor firepit are glowing red it is overloaded.
32. Do NOT lean over this outdoor firepit when lighting or when in use.
33. Do NOT place a hot firepit or hot firepit tools onto combustible surfaces such as grass, wooden deck or furniture.
34. Avoid breathing smoke from the fire and avoid getting it into your eyes.
35. This outdoor firepit should be thoroughly inspected and cleaned on a regular basis.
36. After a period of storage and/or non-use, check for signs of damage and creosote build-up. Do NOT operate until necessary repairs and/or cleanup are executed.
37. Deaths, serious injury or damage to property may occur if the above is not followed exactly.

