
furniturebox

RYE BAR SET

ASSEMBLY GUIDE



SCAN ME

www.furniturebox.co.uk

Scan QR code for more tips,
advice and assembly video or visit
furniturebox.co.uk/club/ryebarset

furniturebox

Important - Please read these instructions fully before starting assembly



SAFETY AND CARE ADVICE



NO POWER TOOLS

SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.
- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre

IMPORTANT INFORMATION

30 MINUTE BUILD

ONE PERSON

MAXIMUM CAPACITY
Table 40Kg, Chair 120Kg

PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.

Bar Chair

LIST OF PARTS		
No	Description	Qty
1	Chair Back	2
2	Front Leg	2
3	Apron	4
4	Chair Seat	2
5	Strecther	4

LIST OF HARDWARE		
No	Description	Qty
A	JCBC Bolt 	12
B	Spring Washer 	12
C	Wood Screw 	14
D	Allen Key 	1
E	Wood Dowel 	8

NOTE: The quantities above are for 2x bar chairs

Bar Table

LIST OF PARTS		
No	Description	Qty
1	Table Top	1
2	Back Table Legs	2
3	Front Table Legs(Left)	1
4	Front Table Legs(Right)	1
5	Long stretchers	1
6	Short stretchers	2

LIST OF PARTS		
No	Description	Qty
A	JCBC 	8
B	Spring Washer 	8
C	Flat Washer 	8
D	Wood Screw 	6
E	Allen Key 	1

NOTE: The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


furniturebox

Bar Chair Assembly

STEP 1

Use a clean, flat, soft surface to avoid any bumps or scratches.

First add the x4 wooden dowels [D] into the seat x2 chair 'aprons' [3].




STEP 2

Attach 2x seat aprons to chair back [1] (apron end with no dowels). Secure with 2x spring washers + 2x bolts [A] on each side - 4 in total.

Attach 2x front legs [2] to other end of seat aprons. Secure with 1x spring washer [B] + 1x bolt [A] on each side - 2 in total.


Carefully slot 2x strecthers [5] into place between the lower legs.

Once everything is in place, tighten bolts with Allen key [D] but avoid over-tightening.



STEP 3

Secure the leg strecthers with 4x wood screws [C].
Then attach the chair seat [4] - you may find it easier to turn the chair upside down and use the edge of a table for support. Secure chair seat with 3x wood screws [C].



STEP 4

Use a clean, flat, soft surface to avoid any bumps or scratches.

Repeat for the 2nd chair.



furniturebox


Bar Table Assembly


STEP 1


Use a clean, flat, soft surface to avoid any bumps or scratches.


Place the tabletop [1] face down. Connect the ‘long stretcher’ [5] to the 2x back legs [2] - the stretcher will slot into the pre-drilled holes on the legs.

Then attach the 2x back legs [2] to the tabletop [1]. Align the pre-drilled holes and connect each leg using 2x flat washers [C] followed by 2x spring washers [B] and 2x bolts [A] per leg. Tighten with Allen key [E].










STEP 2

Attach the 2x short ‘stretchers’ [6]to the back legs and the 2x front legs [3] and [4].
Note leg [3] is front left and leg [4] is frint right.

Connect the front legs to the tabletop. Align the pre-drilled holes and connect each leg using 2x flat washers [C] followed by 2x spring washers [B] and 2x bolts [B] per leg. Tighten with Allen key [E].


STEP 3

Secure the long and short stretchers to the legs using 6x wood screws [D] into the pre-drilled holes.



STEP 4

Carefully and with help, flip your table upright onto its legs. Check for stability. Your new table is now ready to use.





OUR 2 YEAR* GUARANTEE

our products come with a 2 year guarantee to give you peace of mind shopping at Furniturebox

*excludes some garden furniture items which have a 1 year guarantee

WHAT THE GUARANTEE COVERS

PRE-INSERTED FIXINGS
e.g. lose metal threads

FAULTY JOINTS
e.g. legs bending

EXTERNAL FIXING FAULTS
e.g. bonding/glue

STRUCTURAL INTEGRITY
e.g. the frame of the product



ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Unit 6, St Modwen's Park, Chippenham, SN15 5BD
Tel: 01747 863333 Email: sales@furniturebox.co.uk