



4




ROTATE 180°



5



Recommended Maximum Weight



*Unit in Pound(lbs)

WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

00:35
Approx. 35 minutes


Recomm. 1 Person

Tools Required






Assembly Instruction


Modern Simplistic Criss-Crossed End Table (Set of Two)

DIMENSION : 15.6" (W) x 20.0" (H) x 15.6" (D)



NO	HARDWARE LIST	QTY
1	C/B SCREW - A 	32pcs
2	BRACKET 	8pcs
3	C/B SCREW - B 	16pcs
4	CENTER SCREW 	8pcs
5	NAIL LEG 	8pcs


NO	PARTS LIST	QTY
A	TOP PANEL 	2pcs
B	LONG SUPPORT PANEL 	2pcs
C	SHORT SUPPORT PANEL 	2pcs
D	INNER SIDE PANEL 	4pcs
E	LEFT SIDE PANEL 	2pcs
F	RIGHT SIDE PANEL 	2pcs
G	BOTTOM PANEL 	2pcs




USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

1



2



3

