

USER'S MANUAL


6pcs Wicker sofa set

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP!

**FLOOR AREA
2MX2M**




ASSEMBLED BY 2 ADULTS

Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.

Before You Start



- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.







Table x 1

Part	A	B	L	M
Q.ty	2	2	1	1



Chair x 3

Part	E	F	G	H	I
Q.ty	3	3	6	3	3



Corner chair x 2


Part	H	I	P	Q	R	S
Q.ty	2	2	2	2	2	2

SCREW LIST

①	②	③	④	⑤	⑥	⑦	⑧
Bolt M6 x 35 Q.ty 58 pcs	Washer M18 x 1 Q.ty 58 pcs	Bolt M6 x 20 Q.ty 24 pcs	Adjustment Q.ty 24 pcs	Foot Q.ty 10 pcs	Foot Q.ty 14 pcs	Allen key M6 Q.ty 2 pcs	"C" Clip Qty 4 pcs

TABLEx1


STEP 1




① x 4



② x 4




STEP 2





① x 8





② x 8



STEP 3





STEP 4





CHAIRx3




STEP 1





STEP 2



STEP 3





STEP 4






CORNER CHAIRx2





STEP 1








STEP 2



STEP 3



STEP 4



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since Long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

**We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.**

