



Deer Park
Ironworks
1-800-526-9790

Candy Cane Arch

Parts List

- 12 Screws
- 2 Curved Arch Sections
- 2 Curly Peak Sections
- 2 Side Panels
- 4 Ground Spikes



WARNING:

CHOKING HAZARD - Small parts. Not for children under 3 years.

Step 1

Slide both Curly Peak Sections onto one of the Curved Arch Sections and attach with 2 screws.

Step 2

Slide the other Arch Section onto the Curly Peak Sections and attach with 2 screws.

Step 3

Insert both Side Panels into the Arch Sections and attach with 2 screws on each side.

Step 4

Insert the 4 Ground Spikes in the bottom of the Side Panels and attach with screws.

