

Instruction Manual

Please save this manual for future reference.

Product Name:	5Ft Pre-lit Artificial Christmas Tree
----------------------	---------------------------------------

Thank you for purchasing this product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

CARTON CONTENTS:

Description	Quantity
Tree Top (B)	1
Tree Bottom (A)	1
Tree Stand	1
Battery Box	1

Before You Start



- Decide on an appropriate location for your product, please read assembly and Instruction procedure carefully.
Note: This tree may utilize light sets that are marked for indoor and outdoor use, but the artificial tree is for indoor display only.
- Retain the instructions for future use and save the carton for storing your tree.

Assembly and Instruction Procedure (no tools required for assembly):

Remove all packaging (i.e., cardboard or plastic) before beginning. If your artificial tree has snow-flocking, we suggest unpacking the tree on a large cloth. Some of the flocking may come off during unpacking and fluffing of branches.

- Assemble the Tree:

Carefully insert the bottom of the tree section (A) into the stand. Make sure the tree pole is firmly inserted into the stand and turn the screws, so they touch the tree "trunk". Stand the tree upright and straighten by adjusting the tree stand screws in or out. Once the bottom tree section is straight, tighten the screws to secure it. Insert the Top section (B) into the bottom section (A). Connect the connector between section (A) and (B).



Instruction Manual

Please save this manual for future reference.

Product Name:	5Ft Pre-lit Artificial Christmas Tree
----------------------	---------------------------------------

2. Shape the Tree:

Begin to shape the branches from the bottom of the tree to the top. Start with the tree tips farthest away from the center pole.

After shaping the tree, step back to look for any gaps. Reshape branches as needed. You can upsweep the branch tips for uniform look. Once you have the tree the way you want it, you can start decorating!



Fig.1



Fig.2





Fig.3

BATTERY BOX INSTRUCTIONS:

- Open the battery box cover and insert 3 pcs type D batteries. **(not included)**.
 - **Batteries are to be inserted with the correct polarity.**
 - **Do not mix alkaline, standard, or rechargeable batteries.**
- Close the cover back .
- By pressing the button on the battery box, you can achieve the following functions:
 1. STEADY ON WITH TIMER (Automatic Timber: 6h ON, 18h OFF)
 2. TWINKLE WITH TIMER (Automatic Timber: 6h ON, 18h OFF)
 3. OFF



The battery box can be secured to the tree branch using the included hook-and-loop fastener.



Warnings:

1. Risk of Fire and Electric Shock – please follow instructions and warnings on string lights if adding lights to trees.
2. Do not place near fireplaces, candles, outdoor heaters, or other similar sources of heat. This item is not flame retardant.
3. Do not install near pools, fountains, tubs, sinks, or other areas of standing water that the tree may fall or blow into.
4. Keep wires clear of being pinched or cut during assembly or installation. Discard sets with cut or pinched insulation.
5. Make sure final assembly stable enough to hold the tree upright.

Instruction Manual

Please save this manual for future reference.

Product Name:	5Ft Pre-lit Artificial Christmas Tree
----------------------	---------------------------------------

6. Do not use candles on tree. Use only with the pre-installed string lights included.
7. This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.
8. To avoid risk of suffocation to animals or children, dispose of the plastic bag immediately.
9. Do not illuminate while the product is still within its packaging.
10. Do not connect the item electronically to any other item.
11. Do not leave the product operating unattended.
12. Do not allow any plastic parts to come into contact with heat or flames or submerge in water.
13. The supply terminals are not to be short-circuited.
14. **Important:** bulbs are not replaceable.

Troubleshooting:

1. Some bulbs are not lighting, or lights do not come on at all:
 - 1.1 Search for any loose plug connections between the tree sections. Search for loose or missing bulbs.
 - 1.2 Make sure the batteries are installed with correct polarity (and full charged if use rechargeable battery).
2. Tree is not straight:
 - 2.1 Try adjusting the screws in the tree stand to adjust the tree. It is better if the tree is in the vertical position when adjusting.
 - 2.2 Position on a flat level surface.

Note: If these actions do not resolve the issue with the tree, please do not disassemble the tree yet. Please contact customer service for assistance.

Storage:

1. Remove batteries from battery compartment when not in use.
2. Remove all decorations (this does NOT include the pre-installed string lights).
3. Starting from the top, carefully unassembled the tree sections. Press the tree tips back up against the pole.
4. Place the branch sections back into the carton, putting the longest one on the bottom.
5. Store the product in a cool, dry location protected from sunlight where the temperature does not exceed 35°C (95°F).