


Instructions Manual - Issued on 12/12/2023. Please keep for future reference.

Item: 26529

Daylight Floor Lamp



Dimensions


Height: 1935 mm Depth: 226 mm


Width: 226 mm











ValueLights, 4 Omega Drive, Irlam, Manchester, M44 5GR

Thank you for purchasing the Daylight Floor Lamp. This manual will guide you through the setup and operation of the product. Please read the instructions carefully before using the light.


Product Specifications

Material:	ABS, Silicone	
Light Source	LED SMD	
Bulb Wattage:	12w	
Colour Temprature	3000K-6000K	
Lumens	900	
Switch Type	Touch	
Power Cable Colour:	White	
Power Cable Length:	2m	
Protection Class:	Class II	
Waterproof Grade (IP Rating):	IP20 (Protected against solid objects over 12mm, e.g., fingers – Not protected from liquids).	
Power source	Mains	

Contents



Installation Guide



- 1. Assemble and securely tighten the lamp head, pole and base as shown in diagram 1.
- 2. Connect the configured adapter wire to the black and white housing of the floor lamp control button as shown in diagram 2.
- 3. Insert the plug into a main socket, the power button indicator light will stay blue.

Note:


- Please hold the lamp post to prevent it from swinging when adjusting the angle.
- Do not over adjust the nexk of the lamp to avoid damaging the connector components.

Remote Guide

(b)	Main on/off key:Press to turn the main indicator on or off, press and hold within 20 seconds of power on on/off key Pairing successful, main light board flashes prompt			
9	Night key: Short press the light to light up at 20% brightness of color temperature (factory defined night light mode)			
- ` ф́:-	If want defined night mode£ you can choose+/-,color temperature+/- Brightness plus key: Short press to increase the brightness of the light by 1 level (from the min10% to the max 100% brightness, 10 levels)			
	Brightness down key: Short press the light to reduce the current brightness by 1 level (from the max brightness of 100% to the min brightness of 10%, 10 levels)			
(K+	Color temperature plus key: Short press and the light will gradually turn white from the current color temperature. (4000K\4500K\5000K\6000\3000K 5 Level)			
(K-)	Color temperature down key: Short press the light to gradually warm up from the current color temperature(4000K/3000K/6000K/5000K/45000 5 level)			
	Work mode key: Short press the main light to enter (default color temperature 5000K, 80% power)			
	Read mode key: Short press the main light to enter (default color temperature 4000K, 80% power)			
0.5H	Half hour timer key: Press the main indicator for 30 minutes. The 0. 5H indicator on the main panel is on until the time ends. Press again to cancel the timing			
(L)	One hour timer key: Press the main lamp to set the timer for 60 minutes. The 1H indicator on the main panel will light up until the timing ends. Press again to cancel the timing			

Floor Lamp Control





Note:

- After plugging in the power, the indicator light on the control panel illuminate blue.
- Once you have press the power button on the control panel the blue light will go off.
- Before setting the timing, adjust the brightness.
- This product can only use the adapter provided.
- Do not assemble the floor lamp without help.
- Do not use detergent or any other solvents to clean the head of the lamp. Always use a dry cloth.
- Keep the touch keys clean otherwise they may lose the sensitivity.
- Cannot be used on slopes greater than 6 degrees. Keep on a flat level surface.
- Never look directly at the LED lights.
- > If the item is damaged do not switch on at the mains and contact our customer service.
- Do not use a power supply exceeding the rated voltage range (12v)
- Do not change the structure of the lamp. Any improper use or modification of the product may cause damage to the lamp and personal injury.

Important Information

If you need help or have damaged or missing parts, call the Customer Helpline: 0161 837 6095 Opening Times: Monday to Friday, 9am to 5pm. Closed Saturday and Sunday. (By contacting the customer service line your statutory rights are not affected)

Please have the following information to hand:

- ✓ Item Description
- ✓ Item Code
- ✓ Batch number
- ✓ Assembly Instructions

You can also e-mail your requests to us at: customerservice@valuelights.co.uk

Alternatively, you can write to us at: Customer Service Department, Value Lights, 4 Omega Drive, Iram, Manchester, M44 5GR.