Litespan LED Floor Lamp - Color Edition

Lock Connectors

DC rings

OE

Adapter

Before you begin:

- 1. Inspect lamp before beginning assembly. Some wire connections have been made at the factory and the lamp is ready for assembly.
- 2. Remove all packing materials from the lamp.
- 3. To prevent bad connections, avoid pulling wiring connections when removing contents from package or during installation.
- 4. Lay out all the parts on a flat surface.



Assembly Instrustions:


To prevent damage to the pole, please follow the steps below:

- Take the FLEX POLE and feed the POWER CORD through the UPPER POLE.
- 2. Screw the **UPPER POLE** clockwise into the **FLEX POLE**. (Be careful not to pinch the wires.)
- Feed the POWER CORD through the MIDDLE POLE and screw MIDDLE POLE clockwise into the UPPER POLE. (Be careful not to pinch the wires.)
- Feed the POWER CORD through the LOWER POLE and screw LOWER POLE clockwise into the MIDDLE POLE. (Be careful not to pinch the wires.)
- Connect the two ends of the POWER CORD by pressing the LOCK CONNECTORS into place.
- 6. Carefully feed the excess **POWER CORD** into the **LOWER POLE**. (<u>DONOT CUT OR SHORTEN</u> THE POWER CORD).
- 7. Turn and tighten the metal connecting COLLAR onto the base.
- 8. Take out the screw and insert the LOWER POLE into the COLLAR.
- Check direction of the lamp and line up the screw holes and use a screwdriver to tighten the screw.
- 10. BE CAREFUL NOT TO PINCH THE CORD BETWEEN ANY METAL PARTS.
- 11. Connect the **DC plugs** on the external power cord.
- 12. Plug ADAPTER into outlet and now the lamp is ready for use.

CLEANING AND STORAGE

- 1. Before cleaning make sure the lamp is disconnected from the electrical supply.
- 2. Do not use polishes or cleaners. Wipe clean with a soft cloth or rag.
- 3. Store the lamp in a dry, clean and stable place.

Please See Reverse Page for Operating Instructions.



Operating Instructions:

1. Press the power button to turn on the lamp to the 6,000K color temperature level

which is the full spectrum light mode.

2. Pressing and holding the power button again will gradually dim the light to its lowest level, then gradually brighten to its highest level and back to its lowest. When the light level reaches your desired brightness, release the button.

3. Pressing the power button again will turn off the lamp.

4. If the power button is pressed again within 5 seconds the lamp will enter the

4,500K color temperature level which is the soft-white mode. Pressing and holding the power button again will now dim the 4,500K light mode.

5. Pressing the power button again will turn off the lamp.

6. If the power button is pressed again within 5 seconds, the lamp will enter the 3,000K temperature mode which is the warm-white level. Pressing and holding the power button again will now dim the 3,000K light color.

7. If the power button is quickly pressed repeatedly without holding, the light will

rotate between the three different colors

8. If the lamp is turned on after 5 seconds, the light will go back to the last color.

WARRANTY INFO

Thank you for your purchase of the LITESPAN LED Floor Lamp-Color Edition, we hope you're completely satisfied with your purchase.

If you have any questions or are not completely satisfied with your order please contact us at wecare@brightechshop.com, as we will be happy to assist you. Our company provides customers with a warranty of 3 years from the date of purchase.

