



CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Table top		1X
B	Leg		4X
C	Bottom shelf		1X
H1	Flat washer		8X
H2	Spring washer		8X
H3	Allen bolt	 (8x35mm)	8X
H4	Screw	 (4x30mm)	4X
H5	Allen key		1X

Product Dimensions: 23.75"W X 15.875"D X 26.125"H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key



Step

Upside down the table top (A). Attach the leg (B) to the table top (A).

Use the allen key (H5) to tighten the flat washer (H1), the spring washer (H2) and the bolt (H3).

Attach the leg (B) to the bottom shelf (C) and tighten the leg (B) to the bottom shelf (C) with the screw (H4)