

# INSTRUCTION MANUAL



## Parts list ( Subject to actual size; each type of screws and washers has one spare )

<b>Wheel x5</b>	<b>Chair Base x1</b>	<b>Hydraulic Cylinder x1</b>	<b>Mechanism x1</b>	<b>Seat x1</b>	<b>Backrest x1</b>
<b>Armrest x2</b>	<b>Allen Wrench x1</b>	<b>Decorative Cover For Armrest x2</b>	<b>Washer (M6) x8</b>	<b>Washer (M10) x2</b>	<b>Lock Washer (M10) x2</b>
<b>Mechanism Screw (M6x20) x4</b>	<b>Armrest Screw (M8x40) x2</b>	<b>Backrest Screw (M6x30) x4</b>	<b>Headrest x1</b>	<b>Decorative Cover x1</b>	<b>Headrest Screw (M6x30) x2</b>

Note: Before installing the chair, please sort the screws and measure the length of the screws for easy installation.

## Assembled Instructions ( Subject to actual size )

<b>1</b> Press the wheels into the chair base.	<b>2</b> Put the hydraulic cylinder into the hole of the chair base.	<b>3</b> Secure the mechanism and seat with mechanism screws (M6*20) and washers (M6). Pay attention to the direction of installation.	<b>4</b> Secure the backrest and seat with backrest screws (M6*30) and washers (M6).
		<b>No this accessory can be ignored</b>	
<b>5</b> Secure the armrests and backrest with armrest screws (M8*40) and lock washers (M10) and washers (M10) as picture shown.	<b>6</b> Set the upper part of assembled chair on the hydraulic cylinder.	<b>7</b> Secure the headrest and backrest with headrest screws (M6*30), and then put on the cover.	

Note: Before installing the chair, please sort the screws and measure the length of the screws for easy installation.