

INSTALLATION MANUAL

Before Installation

Safety Instructions

- Before use, check that the power supply corresponds to that which is stated on the device's nameplate. Avoid any unintentional startup.
- Do not allow water or other liquids to get into the appliance. Do not expose it to rain.
- Do not use the appliance if the plug, the mains cord or other components are damaged.
- If the mains cord is damaged, you must have it replaced by a service

Environmental precautions


- Used products and batteries must not be mixed with household waste, for proper disposal and recycling of waste electrical and electronic equipment and used batteries, please store them in the collection points provided for this purpose in accordance with national regulations.
- By properly disposing of discarded equipment and used batteries, you will help preserve a valuable resource and prevent the negative impact that waste can have on human health if not properly disposed of.
- For more information on collecting and recycling waste electrical and electronic equipment, please contact your municipality, your waste disposal department.

Specifications and parameters

| | |
|-------------------|------------------|
| Product name | Glass Floor lamp |
| Power supply | 220-240V 50/60HZ |
| Light source | 1xE27 Max 60W |
| Size of the light | D25*150CM |
| | |



Installation Step



1. Thread pole (E) to pole (D).
2. Thread pole (F) to pole (E).
3. Thread pole (F) to top of pole (G).
4. Adjust extra wire into base (G) and attached film (G) to bottom of base (G).
5. Remove socket ring (B) and attached glass shade (C) to thread of lampholder (A) and secure with socket ring (B)
6. Install E27 light bulb (not included).
7. Plug into outlet box and test lamp.