



Instructions:

● 14-adjustable head segments; 3-adjustable waist segments

● Press the head down to the minimum angle and return it to its original state 180 ° back, then readjust it to the desired angle

