

CHIMNEY GLASS

Lamp chimneys are fragile and must occasionally be replaced. The most important dimension to consider when measuring for a replacement chimney is the base diameter (see fig. 1). The base must fit correctly to insure that the chimney is held snugly by the burner. If the remnants of the broken chimney are not available you may instead measure the oil burner itself to determine the correct base diameter for the replacement chimney (see fig. 2).




FIG. 1




FIG. 2