

Description

Name	DK-RR998
Battery	24V7AH
Motor	24V22000 RPM of driving motor 24V5000 RPM of steering motor
Maximum weight	88LBS(40KG)
Dimension	1310*810*600mm
Speed	3-8km/h
Charging time	8-12 hours
Remote control battery	AAA battery 1.5V*2 (not including)
Applicable age	37-95 months
Charger specification	Input: 220V / 110V Output:DC12V1000mA / 28.8V800mA

Charging the Drive Battery:



IMPORTANT! Before using the unit for the first time the battery needs to be charged for at least 8 to 12 hours - no more than 20 hours. Once battery is depleted, recharge for 8 to 12 hours - no more than 20 hours.

IMPORTANT!

Check the drive battery and charger (supply cord, connector) for wear and damage before charging. Do not charge the battery if damage has occurred. Only replace with the same type and voltage rechargeable battery and charger supplied by the manufacturer.

- Only use the rechargeable battery (or equivalent replacement) and charger supplied with your vehicle.
- Always turn power off and charge battery after riding.
- The drive battery should be charged when depleted, or if not used regularly, once a month. Failure to charge the battery as directed will cause permanent damage to the battery and will void the warranty.

STEPS:

1. Locate Charging Port.
2. Plug Charger plug into unit Charging Port.
3. Plug Charger into Wall outlet.
4. When battery is fully charged, unplug charger from the wall outlet and disconnect from charger port.

NOTE: The charger may feel warm during the charging. If excessively hot, unplug and replace.

NOTE: This product has charging protection: When charging, all functions are turned OFF.

Installation And Operation Manual



Model: DK-RR998

Applicable age: 37-95 months

Maximum weight: 88LBS(40KG)

Execution Standard:

GB6675&GB19865 EN71&EN62115 ASTM-F963



Manufacturer: PINGHU DAKE BABY CARRIER CO., LTD

Address: NO.,88, QINSHA SECTION, PINGLANG ROAD, XINCANG, PINGHU ZHEJIANG

US IMPORTER:

Company: Cascade Toys and Games LLC


Address: 14550 Interurban Avenue South, STE A100, Tukwila, WA 98168 US

Land Rover and the Land Rover Logo are trademarks owned and Licensed by Jaguar Land Rover Limited.

1.Spare parts list

Car body 1 PC	Rearview mirrors 1 Pair	Window shield 1 PC
Hood 1 PC	Driving motors 2	Wheel cover 4 PCS
Manual 1 PC	Steering wheel 1 PC	Windows 1 Pair
Seat 1 PC	Remote control 1 PC	Rear wheels 2 PCS
Charger 1 PC	Hood carriage 1 PC	Front wheels 2 PCS
Spanner 2 PCS	Back upper part 1 PC	
MP3 line 1 PC (not including under the MP4 version)		
Decoration on dashboard 1 PC (not including under the MP4 version)		
Screw bag: 1 PC		
Including: M12 gasket - 7 PCS; M10 nut - 1 PC; M4*12mm screw-15 PCS; M4*16mm screw-14 PCS		

2.Part name



- While driving , adult supervision is required all the time
- Always wear a helmet when driving
- Please don't drive near road or on the footpath.
- It is not recommended to drive the vehicle on wet surface or on slope greater than 15-degree.
- It is recommended to drive this vehicle on smooth surface only.
- Please don't drive this vehicle outdoors when it is raining.
- Make sure that the vehicle stop completely before changing direction from forward to reverse
- Please don't allow children to operate the charger or play with the battery
- Clean the vehicle with a dry cloth only.
- Please follow the correct weight and age limits allowed to drive this vehicle.
- It is prohibited to change the circuit or add other electric parts.
- Adults must teach their children about safe driving procedures.
- Please turn the power off when not in use.
- Check the seat to ensure it has been fitted and secured with a bolt before driving.
- Inspect all wires and connection of the vehicle periodically.
- Charging the battery should only be done by adults.
- Charging plug is located underneath the seat.
- In order to avoid accidents, please ensure the vehicle is safe before driving.
- Please don't let children touch the wheels or be near them when the car is moving.
- Please mind fingers when opening and closing doors.

WARNING:
To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water; always wear shoes, and never allow more than 1 rider.

Warning: This toy has no brake.

Warning: This toy cannot be used in the sands.

WARNING!

For safety reasons,
*please use this vehicle under adult guidance and supervision.
*do not use this product on main roads, slopes, highways or other dangerous places.
*children must wear shoes and protective gears when operating the vehicle.
*children should be seated with the seat belt fasten when driving.
*only load a maximum of 35Kg on the vehicle.
*only children aged 37 - 95 months should be allowed on this vehicle.
*use this toy strictly according to safety manual.
*please check the tires, breaks, steering wheels, seats and seat belts before operating vehicle.
*this toy vehicle should be used with caution and requires skill to avoid fall or collision with third parties.
*Non-rechargeable batteries are no to be recharged;
*The supply terminals are not to be short-circuited.
*Rechargeable batteries are to be removed from the toy before being charged;
*The toy should be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.
-Only use the battery specified by the manufacturer
-Only use the charger specified by the manufacturer.
Pictures are for reference only, please adhere to the original Products as standard

The product must be assembled by Adults.

Warning!

Long cord. Strangulation hazard.
Pictures are for reference only, please adhere to the original products as standard

WARNING:

The car contains battery that are non-replaceable.

The instruction manual must be retained since it contains important information.

WARNING:

For the purposes of recharging the battery, only use the detachable supply unit provided with this toy.DC adaptor.

WARNING:

The remote control is not a toy. It is for adult use only, and should not be used by a child. A close adult supervision is always required. Reception range may change significantly with weather, battery, and other environmental conditions.

WARNING:

RISK OF FIRE.DO not bypass.Replace only with JR1922RXS DO 12V Max35.

Troubleshooting

Problem: The vehicle cannot be driven.

Cause of the problem: the battery is insufficient

Please charge in time after each use, and charge at least once a month.


It is recommended to charge for 8-12 hours, not more than 20 hours.

Problem:The car does not move.

Answer : The battery is low, please charge for 8-12 hours

but not exceeding 20 hours.

Charge at least once a month to keep the battery cells active.



To avoid short fuse or power cut off:

1. Do not overload the product. Max load is 35 Kg.
2. Do not drag any item behind this product.
3. Do not allow water or any liquid into electric parts.
4. Do not change wire system without a professional.

TROUBLESHOOTING

Problem:The car only runs for a short time.

Answer 1: The battery is low, please charge for 8-12 hours

but not exceeding 20 hours.

Charge at least once a month to keep the battery cells active.

Answer 2: The battery may need to be replaced depending on its charging history and age.

Problem:The sound does not work.

Please ensure the volume is turned up and the MP3 line is not connected. Sounds from steering wheel will not work when MP3 is plugged in.

Problem:Charger overheating.

It is normal for battery and charger to be slightly warm during charging.



If the charger feel excessively hot, please check for a current overload or battery short circuit.

3. Installation steps



Step1: Get window shield and back upper part out.

A.Take off 11 PCS of M4*12mm screws on the rear carriage and then take off the rear carriage.

B.Take out window shield and back upper part, and then fix the rear carriage with 11 PCS of M4*12mm screws again.




Step 2: Install front wheel



Installation steps

Step 3: Install rear wheel

Install the parts onto the rear axle following sequence as Rear driving motors "L" "R"-real wheels-M10 nut-wheel cover.




Step 4: Install hood carriage, steering wheel and decoration on dashboard.

A. Put the hood carriage onto the car body as the arrow shows from the picture below, and fix it with 4 PCS of M4*12mm screws.


B. Connect the steering wheel properly with the lines on dashboard.

C. Stuck the decoration on dashboard into dashboard when under the MP3 version, it not including under the MP4 version



Instructions

6. Remote control frequency matching




2.4G remote control manual

he first use requires code matching. This product has built-in memory, and it is unnecessary to code after replacing the battery.

1. Turn off the power of the car body, press and hold the "m" key of the remote control, the first indicator light starts to flash after 3 seconds, and then release the key
2. At this time, turn on the power switch of the car body, the first indicator light of the remote control will become normally on, and the code matching is successful
3. When the remote control is not in use, it will enter the sleep state after 10 seconds. Press any key to wake up.
4. Key function description: "forward", "backward", "left", "right", "s" speed regulation, "P" brake.

Press the "s" key to set the speed, one light is low speed, two lights are medium speed, three lights are high speed, only medium speed when reversing

Press the "P" key to enter the braking state, the indicator lights all flash, and press the "P" key again to exit the braking state



Install two AAA / 7 batteries

7. Remote control instructions

Warning! It is not suitable for children under 3 years old.


There are small parts inside and there is a risk of suffocation

- Install two AAA / 7 (1.5V) dry batteries as shown in the figure
- Use a non rechargeable battery, do not charge the battery
- Different types of batteries or old and new batteries cannot be mixed
- Take out the battery from the product in time when the battery runs out
- The positive and negative terminals of the power supply shall not be short circuited
- The package of this product contains important information, please keep it

Warning! The remote control should be used by a guardian. There are small parts inside and there is a risk of suffocation. Please keep away from children.

Instructions

4: Introduction for Dashboard




Description for the switch of Manual / Remote:

Under the Manual: the car only can drive by the child;

Under the Remote: the car only can drive by the remote control;

5. Introduction for MP3




Installation steps

Step 5: Install windows(left&right) and rearview mirrors(left&right)


A.Install windows(left&right) onto the doors, and fix them with 12 PCS of M4*16mm screws.

B.Install rearview mirrors into the sides of windows.




Step 6: Install back upper part

A.Stuck the back upper part into the car body, and fix it with 3 PCS of M4*12mm screws.



Step7: Connect power


Connect the power cable according to the figure below.



Installation steps

Step 8: Install the seat

- Install the seat by 2 PCS of M4*12mm according to the figure below.
- Put the seat into the car according to the figure below.
- Fix the seat by locking the lock catch.



Step 9: Install the window shield

Stuck the window shield into the car, and fix it with 4 PCS of 4*12mm screws.



Step 10: Install the hood


Install the hood according to the figure below.



Installation steps

Step 11: Paste the logo "Range Rover"

Paste the logo "Range Rover" both on hood and rear bumper.
(Two logos are different, please refer to the photo below)



Step 12: Pull handle underneath the back part of the car

There is a pull handle hiding underneath the back part of the car.
Once the car has run out of power, it can be pulled easily with this handle.
(Need to change two motors version with button shows 4*2)

