







ASSEMBLY INSTRUCTION

CLEMENCE RAF DINING BENCH 49"





HARDWARE LIST

HARDWARE LIST			
A		Leg	4Pcs
B		Lock Washers Ø40mm	4Pcs



ASSEMBLY INSTRUCTION


CLEMENCE RAF DINING BENCH 49"




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 127"


Assembly of the sectionals




The prong and connector must be aligned well



How to disconnect





Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette U Shape 117.5"


Assembly of the sectionals



How to disconnect




Lift up the right sectional and pull it out



ASSEMBLY INSTRUCTION


Clemence Dining Banquette U Shape 128"

Assembly of the sectionals



How to disconnect


Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 111.5"-Right


Assembly of the sectionals




The prong and connector must be aligned well



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 88.5"


Assembly of the sectionals



The prong and connector must be aligned well



How to disconnect



Lift up the right sectional and pull it out

