






# Country Cottage 2 Shelf End Table






Thank you for purchasing the Country Cottage 2 Shelf End Table.  
We have found it helpful to have a second person present during the assembly process.

## 2 Shelf End Table Assembly Instructions

### Parts

NO.	DRAWING	DESCRIPTION	QTY.
A		TOP	1
B		POSTS	4
C		SHELF	1
D		BOTTOM	1

NO.	DRAWING	DESCRIPTION	QTY.
E		45MM BOLT	8
F		WRENCH	1



### Step 1

Read through these instructions thoroughly before beginning assembly. We have found this to be of great value when assembling this product.


## Step 2

Remove all parts and hardware from packing material. Wooden pieces should be placed on a non abrasive surface to prevent damage to the finish.

---

## Step 3


Lay Top (A) upside down on a non abrasive surface. Attach 2 Posts (B) using 2-45MM Hex Bolts (E). **NOTE: Do not tighten firmly at this time.**



---

## Step 4

Attach Bottom (D) to Post (B) using 2-45MM Hex Bolts (E). **Note: Do not tighten at this time.** Align Shelf (C) to grooves in Post (B). Attach two additional Post (B) to Top (A) and Bottom (D) using 4-45MM Hex Bolts (E). **TIGHTEN ALL BOLTS AT THIS TIME!**



---

## CARE

Clean with a non abrasive cloth using a mild soap. Make sure to wipe dry.

---

## REPLACEMENT PARTS:

Use the order form on the web site to order your replacement parts. **Thank You!**