
ASSEMBLY INSTRUCTIONS




THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT INFORMATION.
PLEASE READ AND KEEP IT FOR FUTURE REFERENCE.

Before Assembly

- Remove all wrapping materials, staples and packing straps.
- Read the Parts List and Hardware List carefully, make sure all parts and hardware are intact.
- Place all parts on a clean and smooth surface, such as a rug or carpet, to prevent the parts from being scratched.
- Do not cross-thread screws.
- Do not use electric tools.

Make sure all bolts and screws are fully tightened before using chair.


Components



A: 1 PC



B: 1 PC



C: 2 PCS



Ø1/4"x75mm

1: 4 PCS



Ø1/4"x40mm

2: 3 PCS



Ø5/16"x12mm

3: 4 PCS




Ø5/16"x13mm

4: 11PCS



Ø5/16"x19mm

5: 11 PCS



M4

6: 1 PC




12mm

7: 1 PC

1

B	(1 PC)	C	(2 PCS)
3	(4 PCS)	4	(4 PCS)
5	(4 PCS)	7	(1 PC)



2



A (1 PC)



1 (4 PCS)



2 (3 PCS)



4 (7 PCS)




5 (7 PCS)



6 (1 PCS)

3



Safety and Care Advice

Warnings

- Use on level surface only.
- Do not stand on the chair or use it as a ladder.
- Only one person sitting on the chair at a time is permitted.
- Do not use the chair if parts are damaged or screws are loose or missing.
- Do not sit on the edge of the seat. Please always sit properly.
- Do not allow kids to play with the chair.
- Never leave children alone with the chair.
- Severe injuries will occur, if these warnings are ignored.

Cleaning & Maintenance

Cleaning:

- Wipe with a soft, slightly moist cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp tools to clean this chair.

Maintenance:

- Check and tighten all parts regularly.
- If this chair is damaged or seem unsafe, immediately contact us for after sales services.

Limited Warranty

We. promises to repair or replace any product or component that is found to be defective in material or workmanship within one (1) year, from the date of original purchase as the original purchaser owns and uses the products. This warranty is subject to the provisions below.

Exclusions

This warranty does not apply and no other warranty applies to:

- Modifications or attachments to the product that are not approved by Duhome Inc.
- Products that were not installed, used, or maintained in accordance with product instructions and warnings.
- Warranty does not cover color, grain, or texture variations associated with natural wood and grain seen in any finish color.
- Damages caused by exceeding the prescribed weight limit.
- Material fading over time or through sunlight.
- Damages through spills or leaks.
- Collison damage (like rubbing against walls etc.).
- Accidental tears and damage.
- Cigarette or other burns.