
IMPORTANT NOTE


**PLACE ALL PARTS ON CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED

**BEFORE YOU BEGIN, KINDY FOLLOW THE ASSEMBLY INSTRUCSTIONS STEP BY STEP

**DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CASES IS FULLY SET-UP



CARTONS ONLY ONE/HARDWARE LISTS							
PART LISTS				HARDWARE LISTS			
NO	DESCRIPTION	SKETCH	Q'TY	NO	DESCRIPTION	SKETCH	Q'TY
1	Top Panel		1 PC	А	Cam lock	Ĩ	28 PCS
2	Bottom Panel		1 PC	В	Cam bolt	6 2 M	22 PCS
3	Left Side Panel		1 PC	С	Sticker Ø22	\bigcirc	28 PCS
4	Right Side Panel		1 PC	D	Wooden dowel Ø8x30mm		16 PCS
5	Shelf		2 PCS	Е	Hex wrench		1 PC
6	Front Top Rail	E.S. STREET	1 PC	F	Cam bolt	OS M	6 PCS
7	Front Bottom Rail	· · · · ·	1 PC	G	Shelf support pin		8 PCS
8	Left Pillar	55	1 PC	Н	Bolt 5/32x22mm	() manual and a second	2 PCS
9	Right Pillar	i. in	1 PC	Ι	Handle		2 PCS
10	Left Door		1 PC	J	Screws 3.5x14mm	Brown	8 PCS
11	Right Door		1 PC				



PAGE: 3 OF 6

