


Owner Manual



MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :

This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS



Installation:
20 minutes.



Two Person



Before You Start

Please follow the steps below:

-  Unbox the package and check if all parts and accessories are complete.
-  If you find something missing, stop assembly and contact your supplier immediately.
-  Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
-  NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.




Warranty

-  We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.
-  Are you having difficulty with assembly? Missing parts? Please send email with your order number
-  For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram



You can find part B in the left drawer of the first layer!


Parts List (Carton A)

A ×1



Desk Panel


B ×2



Leg


Hardware List (Carton A)

1 ×8+1




Bolt Ø1/4"×3/4"

2 ×8+1



Bolt Ø1/4"×3/4"

3 ×8+1




Spring washer
Ø1/4"

4 ×8+1




Flat washer
Ø1/4"×16×1.2mm

5 ×4




Metal plate

6 ×2




screw
Ø3.5×16mm

7 ×2




screw
Ø3.5×38mm

8 ×2



Wall plug

9 ×4




Bracket

10 ×2




Metal wire

11 ×1



Allen key
M4

12 ×1




Screwdriver

ASSEMBLY INSTRUCTIONS

Step 1

Connect part (5) to part B with bolt (1) , tight bolt with allen key (11) .


1	 x 8	Ø1/4"*3/4"
5	 x 4	Metal plate
11	 x 1	M4




Step 2

Connect part B to part A with bolt (2), spring washer (3) and flat washer (4), tight bolt with allen key (11).

2	 x 8	Ø1/4" * 3/4"
3	 x 8	Ø1/4"
4	 x 8	Ø1/4" * 16 * 1.2mm
11	 x 1	M4




Step 3



Step 4

Connect part (9) to the back of part A with screw (6) , tight screw with screwdriver (11) .



9		x 2	Bracket
12		x 1	Screwdriver
6		x 2	Ø3.5*16mm




Step 5

Install Anti-tip device (9) to the wall in this step.


8	 x 2	Wall plug
9	 x 2	Bracket
7	 x 2	Ø3.5*38mm
12	 x 1	Screwdriver



1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor into the hole with a hammer.



3. Secure the Anti-tip device (9) to the wall with screws (7).

Step 6

10	 x 2	Metal wire
----	---	------------

⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



***This is a permanent label.
Do not remove!***

