


Assembly Instruction Sheet for Model 488884

Package Contents

Part	Description	Quantity
A	Mounting Bracket	1 pc.
B	Ceiling Canopy	1 pc.
C	Lamp Holder	1 pc.
D	Fixture Arm	3 pcs.
E	Hanging Chain	1 pc.
F	Bird Shade	3 pcs.



STEP 1

Remove the Mounting Bracket(A) from the Ceiling Canopy(B).
Mark the drilling position on ceiling with the help of the Mounting Bracket(A).
Drill holes on the marks and stick the expansion anchors into the holes.
Fix the Mounting Bracket(A) to the expansion anchors with self-tapping screws.

STEP 2

Remove the hanging rod from Lamp Holder(C).
Install all the Fixture Arms(D) into the arm plate of Lamp Holder(C).

STEP 3

Connect wire color Black/Red from the Fixture Arms(D) as one strand of wire.
Connect wire color Blue from the Fixture Arms(D) as the other strand.
Connect the two strands of wire with the main wire in the arm plate.

STEP 4

Thread the main wire from arm plate through the hanging rod of Lamp Holder(C) to the Ceiling Canopy(B).
Fix the hanging rod into the Lamp Holder(C).
Install the Lamp Holder(C) back to the arm plate.

STEP 5

Fix the Lamp Holder(C) to loop of the Hanging Chain(E).
Fix the Hanging Chain(E) to the Ceiling Canopy(B).

STEP 6

Insert your bulb (not included) to the bulb base of Fixture Arm(D).

STEP 7

Place the Bird Shade(F) to the bulb base of Fixture Arm(D).
Repeat the above step to place the rest Shades(F).

STEP 8

Hold the Ceiling Canopy(B) close to ceiling.
Connect live line to wire color Black/Red from the Canopy(B).
Connect neutral line to wire color White/Blue from the Canopy(B).

STEP 9

Attach the Canopy(B) to the Mounting Bracket(A).

Your fixture is now assembled and ready to use.