


ASSEMBLY INSTRUCTION



Suggestion

It is recommended to install it near a power source, as later steps will require the power to be turned on.

This product requires installation by at least two people.

Safety Information

Please read all instructions carefully before assembly.
Ensure all parts are properly installed and tightened before use.
Assemble the product on a flat and stable surface.
Keep small hardware parts away from children during assembly.
Do not use the product if any parts are damaged or missing.

Usage Warnings

Do not place excessive weight on the desktop or shelves.
Do not stand or sit on the product.
Use the product only for its intended purpose.
Avoid dragging heavy objects across the surface to prevent damage.

Child Safety Warning

This product is not a toy.
Keep children away from packaging materials and small components.
Children should not climb or play on the product.

Care Instructions

Clean with a soft, dry cloth.
Do not use abrasive cleaners or harsh chemicals.
Keep the product away from prolonged exposure to moisture.

Electrical Safety Warning

Use only the supplied power adapter.
Keep electrical components away from water.
Do not operate the product with wet hands.
Disconnect power before cleaning or maintenance.
Stop using the product if the power cord is damaged.

Sicherheitshinweise

Bitte lesen Sie alle Anweisungen vor der Montage sorgfältig durch.

Stellen Sie sicher, dass alle Teile vor der Verwendung ordnungsgemäß installiert und fest angezogen sind.

Montieren Sie das Produkt auf einer ebenen und stabilen Oberfläche.

Halten Sie Kleinteile und Befestigungsmaterial während der Montage von Kindern fern.

Verwenden Sie das Produkt nicht, wenn Teile beschädigt sind oder fehlen.

Warnhinweise zur Verwendung

Platzieren Sie keine übermäßig schweren Gegenstände auf der Tischplatte oder den Ablageflächen.

Stellen Sie sich nicht auf das Produkt und setzen Sie sich nicht darauf.

Verwenden Sie das Produkt nur für den vorgesehenen Zweck.

Ziehen Sie keine schweren Gegenstände über die Oberfläche, um Beschädigungen zu vermeiden.

Sicherheitshinweis für Kinder

Dieses Produkt ist kein Spielzeug.

Halten Sie Kinder von Verpackungsmaterialien und Kleinteilen fern.

Kinder dürfen nicht auf das Produkt klettern oder damit spielen.

Pflegehinweise

Reinigen Sie das Produkt mit einem weichen, trockenen Tuch.

Verwenden Sie keine scheuernden Reinigungsmittel oder aggressiven Chemikalien.

Halten Sie das Produkt von längerer Feuchtigkeitseinwirkung fern.

Elektrische Sicherheitshinweise

Verwenden Sie ausschließlich das mitgelieferte Netzteil.

Halten Sie elektrische Komponenten von Wasser fern.

Bedienen Sie das Produkt nicht mit nassen Händen.

Trennen Sie die Stromversorgung vor der Reinigung oder Wartung.

Verwenden Sie das Produkt nicht weiter, wenn das Netzkabel beschädigt ist.

installées et bien serrées avant utilisation.

Assemblez le produit sur une surface plane et stable.

Gardez les petites pièces et les éléments de fixation hors de portée des enfants pendant l'assemblage.

N'utilisez pas le produit si des pièces sont endommagées ou manquantes.

Avertissements d'utilisation

Ne placez pas de poids excessif sur le plateau du bureau ou les étagères.

Ne montez pas et ne vous asseyez pas sur le produit.

Utilisez le produit uniquement pour l'usage auquel il est destiné.

Évitez de faire glisser des objets lourds sur la surface afin d'éviter tout dommage.

Avertissement de sécurité pour les enfants

Ce produit n'est pas un jouet.

Gardez les enfants éloignés des matériaux d'emballage et des petites pièces.

Les enfants ne doivent pas grimper sur le produit ni jouer avec celui-ci.

Instructions d'entretien

Nettoyez le produit avec un chiffon doux et sec.

N'utilisez pas de produits de nettoyage abrasifs ni de produits chimiques agressifs.

Évitez une exposition prolongée du produit à l'humidité.

Avertissement de sécurité électrique




Utilisez uniquement l'adaptateur secteur fourni.


























Gardez les composants électriques à l'écart de l'eau.






















N'utilisez pas le produit avec les mains mouillées.


Débranchez l'alimentation avant tout nettoyage ou entretien.

Cessez d'utiliser le produit si le cordon d'alimentation est endommagé.



① x 1 	② x 1 	③ x 1 
④ x 1 	⑤ x 2 	⑥ x 4 
⑦ x 2  ⑧ x 1 	⑨ x 1 	⑩ x 1 
⑪ x 1 	⑫ x 1 	⑬ x 1 
⑭ x 1 	⑮ x 1 	⑯ x 2  ⑰ x 2 
⑱ x 1  ⑲ x 1 	⑳ x 1 	㉑ x 1 
㉒ x 1 	㉓ x 1 	㉔ x 1 
㉕ x 1 	㉖ x 1 	㉗ x 1 

②⑧ x 1 	②⑨ x 2 	③⑦ x 1 
③① x 1 	③② x 1 	③③ x 1 
③④ x 1 	③⑥ x 1 	③⑦ x 1 
③⑤ x 2 	③⑧ x 1 	
③⑨ x 1 	④① x 1 	④③ x 1 
④② x 1 	④④ x 1 	
④⑥ x 1 	④⑦ x 1 	④⑧ x 1 
④⑤ x 1 	④⑥ x 1 	




Easy Installation:

-Can rotate the combination dial clockwise or counterclockwise


Set Your Own Password

- The password can be changed instantly
- No special tools required



1000 Combination Options

Change the password simply by pressing the button and setting the code in just a few seconds



Important Notes:

Password Setting

1. Password must be set when the lock is unlocked (default password is 0-0-0)
2. The reset position is located at the small hole on the lower edge of the outer ring; rotate the head until the internal button becomes visible

(Can be used with accessory O)

3. Insert a small cylindrical rod into the button, press it down, and rotate the combination dial to align your desired numbers in the center
4. Release the button to complete the password setting




Locking & Unlocking

Rotate to lock the device


After locking, randomly turn one or all combination dials to secure the lock


To unlock, rotate the dials to match the preset password

Hardware


A x131  Cam Bolt	B x135  Cam	C x4  68mm Connector Bolt	D x34  Ø8*40mm	E x8  M3.5*45mm	F x8  Plastic End Cap
G x82  M3.5*14mm	H x2  Ø5*355mm	I x12  M3.5*35mm	J x20  M6*12mm	K x8  M8*100mm	L x16  Ø8
M x16  M8 Washer	N x16  M8 Nur	O x1  Ø60 Black Round Wire Box	P x1  Full overlay hinge	Q x1  Combination Lock	AK x16  38mm Hole Cover
S x6  M4*20mm	T x3  96mm CC Black Pull	U x1  Ø60 Black Round Wire Box	V x6  Full overlay hinge	W x2  Black Lifting lug	X x5  Ø10*40mm
Y x2  Push-to-open latch	Z x2  Push-to-open latch	AA x2  Adapter	AB x2  Leg Base	AC x2  Desk Leg	AD1 x2  Framework
AD2 x2  Side Panel	AD3 x2  Short Crossbeam	AD4 x1  Adapter	AD5 x1  Controller	AE x12  M6*30mm	AF x1 
AG x1 	AH x1 	AI x1 	AJ x1 	CR x1  L300mm	DL x1  L350mm
DR x1  L350mm	CL x1  L350mm	CR x1  L350mm	DL x1  L300mm	DR x1  L300mm	CL x1  L300mm
x20  Cabinet Foot	x2  L-Bracket	x2  M8*15mm	x1  Can Lock		

STEP1



A	x4	B	x4	F	x4	E	x4
							
Ø15						M3.5*45mm	


STEP2




DL=350mm
DR=350mm

DL	x1	G	x6
			
L300mm		Ø3.5*14mm	
DR	x1		
			
L300mm			

STEP3



STEP4



STEP5

DL=300mm
DR=300mm

DL x1
L350mm

DR x1
L350mm

T x1

G x6
M3.5*14mm




S x2

STEP6

A x8
Ø15




B x4

STEP7





B	x4


STEP8




A	x12
Ø15	
B	x2


STEP9



D	x2
	
Ø8*40mm	
B	x8
	




STEP10




A	x18
	
Ø15	

STEP11



B	x4
	



STEP12






B	x5
	

I	x1
	
M3. 5*30mm	


STEP13



STEP14






STEP15




I	x4	D	x2
			
M3. 5*30mm		Ø8*40mm	

STEP16




AE	x4	AA	x1	AB	x1	AC	x1	G	x4	AG	x1
											
M6*30mm								M3. 5*14mm			




STEP17



STEP18






STEP19




A	x6
	
Ø15	
B	x6
	

STEP20




A	x8
	
Ø15	
B	x2
	

STEP21




B	x4
	

STEP22




A	x17
	
Ø15	



STEP23



STEP24





STEP25




D	x2
Ø8*40mm	
B	x8


STEP26



D	x2
Ø8*40mm	
B	x8
A	x8
Ø15	




STEP27




I	x4	D	x2
			
M3. 5*30mm		Ø8*40mm	

STEP28




AE	x4	AB	x1	AA	x1	AC	x1	G	x4	AG	x1
											
M6*30mm								M3. 5*14mm			

STEP29




V	x2	G	x4	Y	x1
		M3. 5*14mm			

STEP30




A	x4	Z	x1
Ø15			
G	x10		
M3. 5*14mm			

STEP31




STEP32




A	x4
Ø15	
B	x4



STEP33




STEP34





STEP35




D	x4
	
Ø8*40mm	
B	x7
	


STEP36




D	x4
	
Ø8*40mm	
B	x7
	




STEP37




B	x16	C	x4	D	x4
					
				Ø8*40mm	

STEP38




B	x4	D	x4	U	x1
					
		Ø8*40mm			

STEP39




AD1	x2
	
Framework	
J	x8
	
M6*18mm	
AG	x1
	

STEP40



J	x4
	
M6*18mm	
AE	x4
	
M6*30mm	
AG	x1
	
AD3	x2
	
Short Crossbeam	
AD2	x2
	
Side Panel	

STEP41



X	x3
Ø10*40mm	
AK	x8


M	x8

N	x8


K	x4

L	x8

AF	x1



STEP42



AI	x1

G	x6
M3. 5*14mm	

W	x2

AK	x8

M	x8


N	x8

X	x2
Ø10*40mm	


K	x4

L	x8

AF	x1





STEP43




J	x8
	
M6*18mm	
AG	x1
	

STEP44



AD4	x1
	
Adapter	
AD5	x1
	
Controller	


STEP45



AJ	x1
	
G	x4
	
M3. 5*14mm	

STEP46

This socket comes with two adhesive modules, which can be attached to both ends of the socket.



0	x1
	
P	x1
	