

USER MANUAL

WARDROBE CLOSET WITH DRAWERS AND SHELVES


TOOLS REQUIRED




Phillips screwdriver
(Not included)



Hammer
(Not included)



Drill
(Not included)



Protective blanket
(Not included)



ATTENTION


Keep children and pets away while assembling.




How to use cam locks

CAM LOCK FASTENING SYSTEM


This Cam Lock Fastening System will be used throughout the assembly process.




1




2




3



4







EN

INTRODUCTION

Thank you for choosing our products. Please read the instructions carefully and keep them for future reference. If you need further assistance, please contact our customer service online via email.


PRECAUTIONS


1. When installing the product, use a soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product installation sequence.
5. The structure of this product can not meet the requirements of the placement of heavy items and children climbing.


WARRANTY


We provides an **18 Month** Warranty on all products starting from the date of original purchase. If the product has any manufacturing defect, please contact customer service via email with your order number and other details to the problem. We will send you further information about the return or exchange.

PACKAGE CONTAINS











x3



HARDWARES LIST

A x96




M6*40mm

B x96




M15*11mm

C x60




M3.5*14mm

D x36




M5*40mm

E x6




F x22




M8*40mm

G x2



H x1




H1 **H2**

J x9



L = CR + DR + CL + DL x3




12 inches

K x6




M4*10mm

M x18




M3*12mm

N x1




762MM

P x6




Inset

Q x3




M4*20mm

R x30




S x2



S1 **S2** **S3** **S4** **S5**


T x40



T1 **T2**


M3*16mm

U x2




M8*60mm

V x2




V1 **V2**

W x20


















M3.5*14mm

Y x2























PARTS LIST » A BOX

Unit: (mm)


② x1  1005*480*15 mm	③ x1  1005*480*15 mm	④ x1  1005*480*15 mm
⑤ x1  765*480*15 mm	⑪ x1  768*80*15 mm	⑫ x1  768*80*15 mm
⑮ x1  853*393*3 mm	⑯ x1  553*393*3 mm	㉒ x3  768*80*15 mm
㉓ x3  764*220*15 mm	㉔ x1  999*380*15 mm	㉖ x1  999*380*15 mm
㉗ x1  768*80*15 mm	㉚ x1  768*80*15 mm	㉟ x1  768*60*15 mm

PARTS LIST » B BOX


Unit: (mm)

① x1  800*480*15 mm	⑥ x1  765*480*15 mm	⑦ x1  765*480*15 mm	⑧ x1  800*480*15 mm
⑩ x1  385*464*15 mm	⑬ x2  430*776*3 mm	⑭ x2  776*311*3 mm	⑰ x3  320*120*12 mm
⑱ x3  320*120*12 mm	⑲ x3  720*120*12 mm	⑳ x3  728*315*3 mm	㉑ x3  307*60*12 mm
㉕ x1  700*380*15 mm	㉙ x3  385*447*12 mm	㉛ x1  385*80*15 mm	㉜ x1  385*80*15 mm
㉝ x1  480*400*15 mm	㉞ x1  480*400*15 mm	㊱ x2  385*80*15 mm	㊲ x1  385*60*15 mm

INSTALLATION INSTRUCTION



L = CR + DR + CL + DL



01

C x18pcs




M3.5*14mm


L x3pcs





CL



CR








02

A x22pcs




M6*40mm



03

E x4pcs




04

A x9pcs

M6*40mm

E x2pcs



05

A x2pcs




M6*40mm

B x2pcs



M15*11mm




06

B x8pcs



M15*11mm



07

B x1pc




M15*11mm


F x2pcs



M8*40mm



08




09

A x9pcs



M6*40mm




10

B x9pcs



M15*11mm



11

B x11pcs




M15*11mm


F x2pcs



M8*40mm



12




13


B x11pcs



M15*11mm



14



15

A x6pcs




M6*40mm

F x2pcs



M8*40mm




16

F x4pcs



M8*40mm




17

B x4pcs



M15*11mm




18

B x2pcs



M15*11mm



19

D x4pcs




M5*40mm

U x2pcs



M8*60mm



20


V x1pc

V1

V2

W x2pcs

M3.5*14mm




21

A x10pcs



M6*40mm




22

A x12pcs



M6*40mm




23

B x6pcs



M15*11mm




24

B x6pcs



M15*11mm



25

C x2pcs



M3.5*14mm


G x1pc



F x2pcs



M8*40mm




26

B x6pcs



M15*11mm



27

A x2pcs



M6*40mm

C x2pcs



M3.5*14mm


G x1pc



F x2pcs



M8*40mm




28

B x2pcs



M15*11mm




29

B x4pcs



M15*11mm




30


D x2pcs



M5*40mm



31




32


D x4pcs



M5*40mm



33




34


D x4pcs



M5*40mm



35




36

F x6pcs



M8*40mm



37

A x6pcs




M6*40mm

C x2pcs



M3.5*14mm


H x1pc




F x2pcs



M8*40mm






38

B x4pcs



M15*11mm




39

B x2pcs



M15*11mm




40

D x4pcs



M5*40mm




41


W x16pcs



M3.5*14mm

Y x2pcs





42


V x1pc

V1

V2

W x2pcs

M3.5*14mm




43

D x18pcs




M5*40mm



x3

44




x3

45

A x18pcs



M6*40mm




x3

46

B x18pcs



M15*11mm



x3

47


J x6pcs



K x6pcs




M4*10mm



x3

48


L x3pcs



M x18pcs





M3*12mm




x3

49





50



51


C x12pcs



M3.5*14mm

P x6pcs







52

C x24pcs



M3.5*14mm







The ways to adjust the door


- ► Before adjusting the hinge, please check whether the cabinet is skewed.
- ► If the skew can not be repaired, adjust the cabinet to vertical position.
- ► Please adjust the hinge with the door open.

Obvious gaps between doors or Doors don't look closed




1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.






*** If the 2 doors are overlap, please turn the "internal & external screw" to the left.**

When door is crooked




1 Rotate the "front and rear screws to the left.




*After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right Slightly.


2 Push the door to the cabinet.




3 Rotate the "front and rear screws to the right.




When door is leaning




Turn "internal & external screw" to the left can make the top of the door tilted outward.




Protruding to the upside




Tum "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




1 Tum "up & down screw" to the left.



2 Lower the door's height so that 2 doors are of the same height.



3 Turn "up & down screw" to the right.



***If the door is lower on bottom, please lift up the left door slightly on step 2.**

53


J x3pcs



Q x3pcs





M4*20mm



54

R x30pcs





55


T x40pcs

T1



T2





56 Mandatory!

S x2pcs




For safety reasons, we strongly recommend you follow these instructions to install the anti-tipping hardware, when installed properly, this hardware may prevent the unit from tipping unexpectedly.

⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER open more than one drawer at a time.
- NEVER put a TV on this product.
- Place heaviest items in the lowest drawers.
- NEVER allow children to stand, climb or hang on any drawers,doors, or shelves.

This is a permanent label. Do not remove!



57

S x2pcs





