


ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A	TOP FAME		1PC	C	LEFT LEG		2PCS
B	BOTTOM PANEL		1PC	D	RIGHT LEG		2PCS


HARDWARE IDENTIFICATION

1	BOLT (1/4" x 1/2")		16PCS	6	PALSTIC (8mm)		1PC
2	LARGE L METAL (60 x 60 x 2.0mm)		4PCS	7	L METAL (24 x 13 x 1.5mm)		2PCS
3	SMALL L METAL (270mm)		4PCS	8	PLASTIC LINE (270mm)		1PC
4	SCREW (3 x 14mm)		8PCS	9	LARGE SCREW (8 x 25mm)		1PC
5	ALLEN WRENCH (4mm)		1PC	10	SMALL SCREW (8 x 15mm)		1PC

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4




STEP 5 COMPLETE



FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
This restraint not a substitute for proper adult supervision.
This restraint may provide protection against tipping furniture.
Do not allow children to climb on furniture.
Failure to detach this restraint before moving furniture may
result injury and damage



ASSEMBLY INSTRUCTIONS

