



Recommended Maximum Weight



WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.

Assembly Instruction


5 Shelf Bookcase

00:35


Approx. 35 minutes



Recomm. 2 Person











Tool Required



Customer Support

NEED HELP? For replacement requests or product inquiries, please contact our Customer Service Team.




NO	HARDWARE LIST	QTY
1	CAM SCREW 	4 PCS
2	HIDDEN CAM 	4 PCS
3	CAM COVER 	4 PCS
4	45MM C/B SCREW 	10 PCS
5	SHELF SUPPORT 	12 PCS
6	NAIL 	48 PCS
7	SCREW COVER CARD 	1 PC
8	WALL MOUNT SET 	1 PC

NO	PARTS LIST	QTY
A	UPPER SIDE PANEL	2 PCS
B	BOTTOM LEFT PANEL	1 PC
C	BOTTOM RIGHT PANEL	1 PC
D	CENTER PANEL	1 PC
E	FIXED SHELF PANEL	2 PCS
F	ADJUSTABLE SHELF PANEL	3 PCS
G	BACK PANEL	2 PCS


USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

STEP 8




STEP 7




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

