







PRE-ASSEMBLY:

PARTS LIST

TIPS :

- ✧ Ensure there are no missing pieces pieces by firstly separating and identifying all parts before assembling.
- ✧ Make sure to check packing material for small parts when shipment received to avoid any parts missing during shipment.

Part	Description	Illustration	QTY
A	J		1
B	O		2
C	Y		1
D	Polaris		1
E	Nativity		1

F	Brace		3
G	Plastic tie		8
H	Ground stake		12

ASSEMBLY:

**MAKE SURE TO FOLLOW THE STEPS STRICTLY
FOR A SUCCESSFUL & EASY ASSEMBLY**

1. Remove all components from the box & packaging and lay flat them on the floor to make it easier for you to assemble later.

NOTE: Parts are connected by a string of lights and **SHOULD NOT** be separated. Any separation or disconnection of the light set may cause the unit to malfunction or not light completely.

2. Insert the metal post of brace (F) into the corresponding metal cylinder of J (A) and Y (C). (see Fig.1)




Fig.1

3. Insert the metal post of the upper part of O (B) into the corresponding metal cylinder of the lower part of O (B) and insert the metal post of brace (F) into the corresponding metal cylinder of O (B). (see Fig.2)




Fig.2

4. Insert the metal post of polaris (D) into the corresponding metal cylinder of O (B) and insert the metal post of nativity (E) into the corresponding metal cylinder of O (B). (see Fig.3)

NOTE: Must secure parts with plastic ties (G) to make sure the best of stability, or it will be less of wind rating and stability for outdoor use!




Fig.3

5. Secure the base to the soft ground by fully inserting the ground stakes (H) through the circle on the base into the ground.

WARNING: This step is a **MUST-HAVE** or it will be less of wind rating and stability for outdoor use! It is NOT supposed to be a quality issue.




Fig.4

6. Connect the plug to the extension cord with A to A, B to B... and plug the light set into a standard 120-volt AC electrical outlet.(Fig.5)

WARNING: DO NOT plug into a wall outlet until item is fully assemble and lights are properly connected.

WARNING: A must be connected with A, B must be connected with B, otherwise it will lead to part of the light is not bright, it's not a quality issue.




Fig.5

7. This product can be used in two ways. It can be placed in the yard or hung up for decoration. You can remove the brace and use the plastic ties (G) to hang this product. (see Fig.6)




Fig.6



WARNING:
Please Assemble **OUTSIDE** IN AREA
to Avoid Unexpected Cleanup due to
Nature of Glitter!

- ✧ Product may contain glitter, **DO NOT** assemble indoors to avoid unintended property cleanup.
- ✧ **DO NOT** plug into a wall outlet until the item is fully assembled and lights are properly connected.
- ✧ **DO NOT** use in extreme weather conditions.
- ✧ This item is **NOT** intended for permanent installation or use.
- ✧ **UNPLUG** item when not in use.
- ✧ If any parts are missing, broken, damaged, or worn, **STOP** using this product until repairs are made.
- ✧ **DO NOT** allow glitter to contact your eyes or face as this may result in skin irritation or injury.
- ✧ Keep this product away from all heat sources.
- ✧ **DO NOT** secure wiring with staples, nails, or sharp hooks.
- ✧ **DO NOT** hang ornaments or other objects from the cord.
- ✧ **UNPLUG** item before removing or changing bulbs.
- ✧ Replace burned-out bulbs **IMMEDIATELY**.

OTHER RECOMMENDATIONS :

- ✧ To ensure the final unit is secure and sturdy, it is **HIGHLY RECOMMENDED** to secure each component with the zip ties provided after connecting each component together.
- ✧ Parts may be connected by a string of lights and **SHOULD NOT** be separated. Any separation or disconnection of the light set may cause the unit to malfunction or not to light completely.

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Troubleshooting Guide



Problem	Solution
Unstable or Difficult to Assemble	✧ Ensure the product is placed on a flat & level surface
Works Improperly	✧ Verify the product is securely plugged into a wall outlet or a UL-listed power cord. ✧ Do not plug into other electrical items.
Product Fails to Light Up	✧ Inspect for loose/broken bulbs, faulty connections, or unplugged cords.
Partial Lighting (Multiple Light Strings)	✧ If the product has multiple light strings, make sure all power cords are correctly connected to the power supply (e.g., A is connected to A, B is connected to B).

Care and Help Center



- ✧ Wipe the unit with a damp cloth and allow the unit to dry before storing.
- ✧ Carefully disassemble the unit and take caution not to cut any electrical wires.

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.