





Model:T3963P447211


PRODUCT GUIDE AND INSTALLATION MANUAL







Parts List:




A1	A	A2	B	B1	C	C1	D
1pcs	1pcs	1pcs	4pcs	6pcs	1pcs	1pcs	1pcs



E1	E2	F	F1	H1	H2
2pcs	2pcs	1pcs	1pcs	1pcs	1pcs




Q	T	T1	T2
1pcs	20pcs	10pcs	4pcs
	M6x30mm	M6x50mm	M6x55mm




T3	T4
8pcs	4pcs
M8x35mm	M8x15mm

ASSEMBLY


STEP 1




STEP 2



STEP 3




STEP 4




T3	04pcs
T4	04pcs


STEP 5




STEP 6




STEP 7




STEP 8



STEP 9




STEP 10



T	02pcs
T2	04pcs

STEP 11



STEP 12

