














COAT RACK

MONTAJ KLAVUZU / ASSEMBLY MANUAL











AKSESUAR LİSTESİ / ACCESSORY LIST

A23  24x	A22  24x	A04  26x	A17  18x	A20  8x
F05  4x	A24  8x	A06  24x	A10  10x	A10  8x
A14  4x	A48  30x			

PARÇA KODLAMA / DISASSEMBLED VIEW



1



2














Diagram 3 illustrates the process of attaching the front panel (1) to the side panel (9). The front panel is shown being aligned with the side panel. Screws (A17) are used to secure the front panel to the side panel. A hand is shown using a screwdriver to tighten the screws. The diagram also shows the front panel being attached to the bottom panel (12) using screws (A17).


5



6



7



8

