



CEILING FAN WITH LIGHT




INSTALLATION MANUAL

TOOLS REQUIRED				
				
	Ladder	Pliers	Wire Strippers	Screwdrivers




01

PACKING LIST



02

INSTALLATION KIT

AA 1×  Mounting Bracket	BB 2×  Outlet Box Screw with Washer	CC 1×  Clevis Pin & "R" Pin	DD 15×  Fan Blade Tail Screw
EE 20×  Fan Blade Screw	FF 15×  Fan Blade Arm Screw	GG 3×  Wire Nut	HH 1×  Gloves

NOTE:

1. Some extra hardware may be included. The quantity listed above is the number required for installation.
2. Parts "CC" have already been installed with Long Downrod Assembly, parts "FF" have been installed with Fan Motor Assembly. They need to be disassembled before installation.


03

INSTALLATION

1. Removing the Mounting Bracket

Step 1. Take off the screws from outlet box.

Step 2. Secure the mounting bracket (AA) onto the outlet box with screws taken off or Outlet Box Screw With Washer (BB) provided.




2. Assembling the Fan Blades

Step 1. Insert Fan Blade Tail (K) and Blade Arm (L) respectively into the corresponding interlayers of the Fan Blades (J).

Step 2. Fix Fan Blade Tail (K) and Blade Arm (L) to Fan Blade (J) respectively using Fan Blade Tail Screw (DD) and Fan Blade Screw (EE).

Note:

① The Blade Arm square convex surface needs to upwards, and it is installed in the interlayer of the fan blades.




3.Installing the Fan Blades

Step 1. Take off Fan Blade Arm Screws (FF) from the Fan Motor Assembly (F).

Step 2. Fix Blade Arm (L) to Fan Motor Assembly (F) with the removed Fan Blade Arm Screw (FF).

Note:

①Make sure to assemble the blades in sequence and fasten the screws with equal force.



4.Assembling the Fan


Step 1. Assemble the Canopy and coupling cover, route wires from the fan through the downrod.

Step 2. Loosen the set screw from the yoke but do not take off, align the holes at the bottom of the downrod with those in the yoke.

Step 3. Carefully insert the clevis pin (CC) through the holes in the yoke and downrod (Be careful not to jam the clevis pin against the wires inside the downrod).


Step 4. Insert the "R" pin (CC) into the end of the clevis pin.

Step 5. Tighten the set screw on the yoke to secure the downrod.



5. Hanging the Fan

Step 1. Lift the downrod into the mounting bracket. Rotate the downrod until the seat tab in the mounting bracket is seated in the groove in the downrod ball.



6. Wiring


Step 1. Insert the receiver to the mounting bracket

Step 2. Connect the wires from the fixture to the house supply wires with wire nuts (AA) , ground wire (green, green/yellow, or bare copper) to ground wire, neutral wire (white or blue) to neutral wire, and hot wire (black or brown) to the hot wire.

Step 3. Wrap the connection with electrical tape.

Note:


- ① This fan only needs one set of input wires (black, white, and ground wire). Both of the fan and lights will be controlled by the remote control.
- ② This fan can only be connected to an on/off switch if you have one, not a dimmer switch.



7. Attaching the Canopy

Step 1. Slide the canopy up to the ceiling and attach it to the mounting bracket with the set screws provided.


Step 2. Slide the coupling cover downward to cover the yoke and fix the canopy ring to the canopy.



8. Installing the Light Shade


Step 1. Connect the Light Wires from the Light Kit to the fixture wires.

Step 2. Rotate the light Shade (G) clockwise to secure it to the Fan Motor Assembly (F).



04

REMOTE CONTROL INSTRUCTIONS



①: Turn off power.

②: Turn on/off the light.

③: Fan moves forwards or reversely.

④: Turn on/off the mute mode.

⑤: Turn on the fan on 1/2/3/4/5/6 speed.

⑥: Turn off the fan.

⑦: 1H/4H/8H for timing the fan.

⑧ ⑨ ⑩: Adjust the light color temperature.



⑪ ⑫: Adjust the brightness of the light.

REMOTE SIGNAL PAIRING:

If the remote control loses signal of the fan, press and hold the button ⑥ at the very beginning after it's turned on from wall switch. After the fan light flashes or beeps, it's done.

05

APP CONTROL INSTRUCTIONS



-  Pair button. Click it within 5 seconds after the fan is powered on from wall switch. After the fan flashes or beeps, it has been successfully paired with the phone, it can be controlled through it.
-  Slide to change the fan speed.
-  Slide to change the brightness of the light.
-  Quick switch for "White" light color. (Not supported)
-  Quick switch for "Yellow" light color. (Not supported)
-  Quick switch for "Natural" light color. (Not supported)
-  Night mode: Dim the lights. (Not supported)
-  Fan moves forward.
-  Fan moves reversely.
-  Change the direction of the wind. (Not supported)
-  Timing the fan.
-  Natural wind: The fan speed will change automatically when you use this function.
-  Sleeping wind. (Not supported)
-  Turn on/off the light.
-  Turn on/off the fan.
-  Unpairing: Click the unpair button within 5 seconds after turning on the fan. Once the fan flashes or beeps, it has been successfully unpaired from your phone.