


ASSEMBLY INSTRUCTIONS


36" Round Dining Table (3 Boxes)



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if the following part arrives damaged:

Part # - Table Top

Tempered Glass Warning : Should the tempered glass chip at ANY point throughout ownership, please immediately discontinue use of the table to avoid injury.

CAUTION : DO NOT place hot objects (100°F or more) directly on the glass surface.

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step 1: Use Bolt D、I, to connect Part ② to Part ③.

Assembly Step 2: Use Bolt A, to connect Part ② to Part ①.

Assembly Step 3: Use Bolt D、I, to connect Part ④ to Part ③

+ Parts Included

① Table Top(1PC)

② Top Plate(1PC)



③ Leg(1PC)

④ Bottom Plate(1PC)



+ Hardware Included

A Screw(4PCS)

B Spring Washer(10PCS)



8*12mm



6*12mm

C Flat Washer(10PCS)

D Screw(6PCS)



6*16mm



8*30mm

E Allen Key(1PC)

F Allen Key(1PC)



G Flat Washer(2PCS)

H Spring Washer(2PCS)



12*24mm



12*20mm

I Screw(2PCS)




12*40mm

ASSEMBLY INSTRUCTIONS


36" Round Dining Table (3 Boxes)

1




- a) Position Leg (3) and Top Plate (2) as shown and align screw holes on both parts.
- b) Use Screw (D) fitted with Spring Washer (B) and Flat Washer (C) to fasten (2) to (3). Use Allen Key (E) to drive (D). Do not tighten (D) completely until all 3 screws are in place.
- c) Use Screw (I) fitted with Spring Washer (H) and Flat Washer (G) to fasten (2) to (3). Use Allen Key (F) to drive (I) and tighten (I) completely in place.

2



- a) With assistance, lay Table-top (1) flat with the bottom-side facing up on a material that does not scratch or damage the part.
- b) Position Leg with Top Plate from STEP 1 as shown and align the screw holes on top Plate to screw holes on bottom side of (1).
- c) Use Screw (A) fitted with Spring Washer (B) and Flat Washer (C) to fasten Top Plate to Table Top. Use Allen key (C) to drive (A). Do not tighten (A) completely until all 4 screws are in place.

3



- a) Position Bottom Plate (4) as shown and align screw holes on (4) to the screw holes on the leg.
- b) Use Screw (D) fitted with Spring Washer (B) and Flat Washer (C) to fasten (4) to (3). Use Allen Key (E) to drive (D). Do not tighten (D) completely until all 3 screws are in place.
- c) Use Screw (I) fitted with Spring Washer (H) and Flat Washer (G) to fasten (4) to (3). Use Allen Key (F) to drive (I) and tighten (I) completely in place.
- d) 2 People Required to Set the table right-side up.

4



The assembly of the table is complete.