Daisy Solar Lantern Instructions:



Hanging Handle Metal shell Metal Lantern Solar Housing

Instructions:



1. Take Off Solar Housing Lift out the Solar Housing from the top of the metal shell.



2. Slide Power Switch On
On the bottom of the solar housing,
slide power switch from the "Off"
position to the "On" position. Return
solar housing to metal shell.



3. Place In Sunlight And Enjoy!
Place outside with the solar panel up to catch **direct sunlight**. The LED will illuminate automatically in darkness.

Further Instructions:

Placement Matters!

- Place the lantern somewhere that the solar panel will receive at least 6 hours of direct sunlight.
 If you place it under a tree, make sure it is not too shaded by foliage or branches that prevent it from charging.
- 2. Place the lantern away from nighttime light sources. This way the light sensor will be triggered to turn on at sundown.
- 3. If your lantern does not glow well, change the location to see if you have more success.
- If lantern becomes dim or goes out, there is a rechargeable AA battery that is replaceable. Batteries typically last 1-3 years.
- 5. Lanterns are designed to be outside. However, during harsh winters you can prolong the life of your lantern by turning it off and storing indoors.



4+ hr.

Flashing or dimming light indicates low battery

Will glow 4+ hours when placed in direct sunlight. Cloudy weather will result in less glowtime.



THANK YOU FOR YOUR PURCHASE!

We want you to be completely satisfied. If you have any questions please contact our customer service department.

SUPPORT@ALLSOPGARDEN.COM 800-426-4303

Love your product?

Follow and Tag us @allsopgarden with #allsopgarden

