

## NOTICE

\*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

\*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

\*This item may require periodic tightening.

Product Dimensions: 23.62" W x 22.83" D x 33.07" H

## PREPARATION

\* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

\* If any part is missing or damaged, do not attempt to assemble the product.








\* Estimated Assembly Time: 10 minutes.


\* Tools Required for Assembly (included): Allen Key

### CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use. Remove wooden furniture from standing water. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

### Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Frame Seat		1X
B	Frame back		1X
C	Frame leg		2X
HW1	Screw: M7 x0.5 x90 mm	 M7x90	2X
HW2	Screw: M7 x0.5 x60 mm	 M7x60	4X
HW3	Allen Bolt: M8x0.5x50 mm	 M8X50	2X
HW4	Allen key 4	 LG4	1X



**Weight Capacity : 242 lbs**

**Warning : Do not stand on chair**

**Warning : Do not over torque bolts / screws**

# PREPARATION


\*Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

\*If any part is missing or damaged, do not attempt to assemble the product.

\*Estimated Assembly Time : 10 minutes.

\*Tools Required for Assembly (included): Allen Key


1



## Step 1

Attach Frame back (B) to Frame Seat (A), use Screws (HW2) tighten with allen key (HW4).

2



## Step 2


Attach Frame leg (C) to Frame seat (A), use Screws (HW1) tighten with allen key (HW4).

Attach Frame back (B) to Frame leg (C), use Bolts (HW3) tighten with allen key (HW4).

## PREPARATION

---

- \*Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- \*If any part is missing or damaged, do not attempt to assemble the product.
- \*Estimated Assembly Time : 10 minutes.
- \*Tools Required for Assembly (included): Allen Key



Step 4

Caution: This Chair can only be used on a flat, level surface