

ASSEMBLY INSTRUCTION

GROUP NO.: F2530



DESCRIPTION: DINING TABLE

Read instruction carefully prior to assembly .


Thank you for purchasing this quality product. Check carefully for small parts which may have come loose during shipment.

Remove all components from pack and place table top upside down on soft surface such as carpet or cloth to prevent scratching the finish. Identify and count all parts as specified below.


Do not tighten bolts until assembly is complete

NO.	HARDWARE PACK		Q'TY	NO.	PARTS		Q'TY
A		ALLEN BOLT (Ø 5/16"*75mmL)	8PCS	1		TABLE TOP	1PC
B		LOCK WASHER (Ø5/16")	8PCS				
C		FLAT WASHER (Ø5/16")	8PCS	2		TABLE LEGS	4PCS
D		ALLEN KEY (4MM)	1PC				


STEP 1



STEP 2



STEP 3



STEP 4

