ASSEMBLY INSTRUCTIONS



FLOOR LAMP

PAGE 1 OF 4

Assembly Instructions

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Warning!




- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediate
- 2. This product is for home use only and not intended for commercial establishments.

PARTS IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q,TY	HARDWARE PACKAGE			
Α	PLATE	•	1 PC	NO I	DESCRIPTION	FIGURE	Q,TY
В	LAMP BODY	→	1 PC	1	WRENCH	5=C	1 PC
С	BASE	\odot	1 PC				
D	SHADE		1 PC				
E	RING	-	1 PC				
F	FLAT WASHER	•	1 PC				
G	SPRING WASHER	•	1 PC				
н	NUT		1 PC				
1	HOLLOW SCREW	_	1 PC				
J	SCREW	•	1 PC				
K	LIGHT BULB		1 PC				


PAGE 2 OF 4



As a safety feature, and to reduce the risk of electric shock, this portable lamp includes a polarized plug (one blade is wider than the other). The plug will fit into a polarized outlet in a single direction only. If the plug does not fit fully in the outlet, reverse the plug and try again.

If it still does not fit, contact a qualified electrician. DO NOT use with an extension cord unless, can be fully inserted. DO NOT alter the plug.

FLOOR LAMP: TYPE A LED BULB 9W



Note: Dimension tolerance ±5%