



ASSEMBLY INSTRUCTION







Read the instruction carefully. Remove all the wrapping materials, staples and straps from the carton. Refer to the hardware and furniture parts list as a guidance. Make sure you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface such as carpet to prevent from scratches.

CAUTION: KEEP ALL HARDWARE PART OUT OF REACH OF CHILDREN.

PART LIST


ITEM	DESCRIPTION	QTY
A	CHAIR BACK FRAME	1
B	FRONT LEG	2
C	CHAIR SEAT	1

HARDWARE LIST


ITEM	DESCRIPTION	QTY
D	JCBC SCREW M6 X 45MM 	2
E	JCBC SCREW M6 X 60MM 	4
F	JCBC SCREW M6 X 80MM 	4
G	FLAT WASHER 1/4" 	10
H	SPRING WASHER 1/4" 	10
I	ALLEN KEY M4 	1

STEP 1:

Attach Cushion Seat (C) to chair back (A). Do not tighten the JCBC screw (D) until step 3.



STEP 2: Do not tighten the JCBC screw (F) until step 3.



STEP 3: Insert front leg (B) to Cushion seat (C) with JCBC screw (E). afterwards give the chair stands, and make sure is stable then all tighten all the screw.

