
ASSEMBLY INSTRUCTION




6672MS - CORNER MEDIA STAND



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. Identify and count all parts and compare with the parts list below.



ASSEMBLY INSTRUCTION :


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly
4. **Hand fasten bolts and align parts before tightening with Allen key**

No.	COMPONENT		Q'ty
Ⓐ		Top	1
Ⓑ		Shelf	1
Ⓒ		Bottom plate	1
Ⓓ		Back plate	1

No.	COMPONENT		Q'ty
Ⓔ		Side (L)	1
Ⓕ		Side (R)	1
Ⓖ		Legs	3
Ⓗ		Legs	2

No.	HARDWARE LIST Q'ty		Q'ty
①		Allen key k4	1
②		Bolt M6x30	12
③		Bolt M6x15	17
④		Spring washers Ø10/Ø6*1.2	29
⑤		Flat washers Ø16/6Ø*1mm	29


Step 1: This unit is to be assembled upside down




ASSEMBLY INSTRUCTION

6672MS - CORNER MEDIA STAND

Step 2




Step 3



ASSEMBLY INSTRUCTION


6672MS - CORNER MEDIA STAND

Step 4



Step 5


Tip For Assembly: Hand fasten bolts and align part D with parts E and F to prevent larger than normal gaps between parts.



ASSEMBLY INSTRUCTION

6672MS - CORNER MEDIA STAND

Step 6



Finish