

## **Assembly Instructions**

Product Dimensions:  
22.44"L×5.51"D×37.80"H

Please take a moment to read through the entire instruction booklet before assembly to familiarize yourself with this product. Once you feel ready to start, follow the instructions step by step and this should make this process as easy as we could make it for you.

# WARNING CAUTION

## ADULT ASSEMBLY REQUIRED

### CHOKING HAZARD

- This product includes small parts, sharp points and sharp edges in its unassembled state. Keep unassembled parts away from children under 3 years of age, and animals.

### SAFETY WARNINGS

- Follow the information on the warnings appearing on table and on the carton. Do not remove warning label from cabinet.
- Do not allow children under 3 years of age to use the cabinet.
- Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.

### FURNITURE TIP-OVER HAZARD

#### Children have died from furniture tip-over

To reduce the risk of furniture tip-over:

- ALWAYS install tip-over restraint especially if used by a wall or in the open.
- NEVER put a TV on this product
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- ALWAYS place heaviest items in lowest cabinet.

### PARENTAL SUPERVISION IS REQUIRED


- Parents or Guardians should supervise use under the intended age specifically regarding children that may have access to it and climb on the unit.
- Do not allow horseplay on, under, or behind the unit and prohibit jumping on the cabinet.
- If used improperly, your table may be pulled over or fall, creating risk of injury or damage. Children should not be permitted to climb or pull on the cabinet.

### USE, MAINTENANCE & ASSEMBLY

- Periodically check and ensure that the components are in their proper position, free from damage, and that all connectors are tight.
- Use on level surfaces only. Assemble on a soft level surface to avoid damage to unit or floor.
- Do not use this item if any components are missing or damaged.
- Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- Only clean using damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- Check you have all components and tools listed on page 4
- Do not stand or put weight on this product during assembly, this could cause damage.
- Remove all hardware from the plastic bags and separate them into groups.
- Assemble the item as close to its final position (in the same room) as possible.
- Certain assembly steps may be easier with 2 people.
- Dispose of all packaging carefully and responsibly.
- We do not recommend power screwdrivers. Only use hand screwdrivers to prevent damage to unit.
- Keep these instructions for future reference.

# ASSEMBLY AT A GLANCE

Please take a moment to read through the whole instruction booklet before assembly to familiarize yourself with this product. Once you feel ready to start, follow the instructions step by step and this should make this process as easy as we could make it for you.




This drawing is to give you an overall idea only of how this assembly will go together and does not replace the assembly instructions.

# COMPONENT PARTS


Please check that you have all the parts listed below

1. Top Table Panel ×1
2. Middle Panel ×2
3. Bottom Panel ×1
4. Left Side Panel ×1
5. Right Side Panel ×1
6. Left Side Table Panel ×3
7. Right Side Table Panel ×3



## ASSEMBLY HARDWARE

**A**




Cam Bolt ×12+1pcs

**B**



Cam Lock ×12+1pcs

**C**



Wood Dowel  
Pin ×27+2 pcs

**D**




Screw ×2

**E**




Screw ×30+2 pcs

**F**




Power Supply ×1

**G**



Hex Screwdriver ×1

**H**




×6

# ASSEMBLY INSTRUCTIONS


**1**

Select 1 (×1) and A(×4).  
Insert A(×4) into 1.



**2**


Select 6(×1), 7(×1) and B(×4).  
Insert B(×2) into two holes of 6  
and install 6 into 1 with A(×2).  
Repeat for 7 and B(×2).



# ASSEMBLY INSTRUCTIONS


**3**

Select C(×3) and E(×4).  
Insert 2 into 6 and 7 with C(×3).  
Insert E(×4) into 2.



**4**


Select A(×4).  
Insert A(×4) into 2.



# ASSEMBLY INSTRUCTIONS


**5**

Select 6(×1) , 7(×1) and B(×4).  
Insert 6 and 7 into 2 with A(×4).  
Insert B(×2) into 6.  
Repeat for 7 and B(×2).



**6**


Select C(×3) and E(×4).  
Insert 2 into 6 and 7 with C(×3).  
Insert E(×4) into 2.



# ASSEMBLY INSTRUCTIONS


**7**

Select A(×4).  
Insert A(×4) into 2.



**8**

Select 6(×1) , 7(×1) and B(×4).  
Insert 6 and 7 into 2 with A(×4).  
Insert B(×2) into 6.  
Repeat for 7 and B(×2).






# ASSEMBLY INSTRUCTIONS


9

Select 3(×1), C(×3) and E(×4).  
Insert 3 into 6 and 7 with C(×3).  
Insert E(×4) into 3.



10


Select 5(×1), C(×8) and E(×8).  
Insert 5 into Cabinet with C(×8)  
and E(×8).



# ASSEMBLY INSTRUCTIONS


**11**

Select 4(×1), C(×10) and E(×10).  
Insert 4 into Cabinet with C(×10)  
and E(×10).



**12**


Select D(×2) and F(×1).  
Insert F into the hole of 1 with  
D(×2).



# ASSEMBLY INSTRUCTIONS

**13**

Select H(×6).  
Insert H(×6) into 3.



# ASSEMBLY COMPLETE

