

ASSEMBLY INSTRUCTION


ADJUSTABLE BED

PACKING LIST

Adjustable Base

A


The Bed Base



1 PC

B


Legs and Washer



6 PCS

C

Retainer Bar



1 PC

D

Remote Control



1 PC

E

Adaptor




1 PC

Please check the packing list while unpacking the box to ensure you received all necessary parts for assembling the bed base.


As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.




- 1** Mount the legs and washer (B) into the bed base (A) if necessary.






- 2** Put the retainer bar (C) into the presetting hole on the foot of bed.



- 3** Wiring Diagram: Customers only need to connect the adaptor (E). Other wires are already connected.



Notice: The weight must be spread while the motor running.
Please don't focus the weight on head or foot of bed.



CLEANING & CARE

1. Please cut off the power if unuse the bed for long time.
2. Clean surfaces with a dry or damp soft cloth.

Make sure the motor control system is well connected before use.

INSTRUCTION MANUAL OF REMOTE CONTROL SYSTEM



DESCRIPTION OF THE BUTTON FUNCTION



HEAD UP : Long press the button to adjust the head section of the bed base Up.



HEAD DOWN : Long press the button to adjust the head section of the bed base down.



FOOT UP : Long press the button to adjust the Foot section of the bed base Up.



FOOT DOWN : Long press the button to adjust the Foot section of the bed base down.



FLASHLIGHT : Press the button and turn on the flashlight. Press again and turn off the under light.



ZERO G : Pressing this button will bring the bed base to the preset ZERO G position.



ANTI SNORE : Pressing this button will bring the bed base to the preset Anti-Snore position.



TV : Pressing this button will bring the bed base to the preset TV position.



FLAT : Pressing this button will bring the bed base to FLAT position.

BUTTON TIPS

1 ZG/ANTI SNORE/TV/FLAT these positions can be interrupted by pressing any other buttons

2 THE TV & ZG & ZZZ position can be reset to your preference. Following these steps.

1. Adjust the bed base to your preferred head & foot position.
2. Long press the FOOT UP & DOWN buttons  simultaneously until the LED lights flash.
3. Release the buttons and press TV button before LED stop flashing.
4. After all these setting, the TV position has been reset.

SAME method to reset other memory positions

3. Remote Matching Instruction

Matching the wireless remote with control box
(try this when you can't control the bed with the remote)

1. Plug the power adaptor for adjustable base which need to be controlled.
(If the bed are powered to begin with, power off for at least **60** seconds and then on power again)
2. Simultaneously press and hold the HEAD UP & DOWN buttons  on the remote, keep 3 seconds until the lights flash.
3. When they begin flashing release all buttons, then the matching is completed.



NOTES

Step 2 should be completed within 2 minutes after the control box is powered on. If you need to control more than one bed at the same time, you can power up all the beds within 2 minutes and set above steps

QUESTIONS? CONTACT US:

- EMAIL: customerservice@hkfoam.com

If in any case, you are not 100% happy with the item received, would you please contact us first and give us a chance to make it right for you? All of our products are covered by warranty and we will do our best to address any of your concerns. We are dedicated to your 100% satisfaction with your order.