
Kitchen Island Cart

Assembly Instructions - Please keep for future reference

N707P404588 / N707P404589



Important - Please read these instructions fully before starting assembly

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-























Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note:The quantities below are the correct amount to complete theassembly. In some cases, more fittings may be supplied than required.


HARDWARE BOX INSIDE BOX 2

1 QTY: 36  CAM BOLT	2 QTY: 36  CAM LOCK	3 QTY: 28  WOOD DOWEL Ø6*25mm
4 QTY: 6  BALL BEARING GLIDE	5 QTY: 6  BALL BEARING GLIDE	6 QTY: 36  FLAT HEAD SCREW Ø6*12mm
7 QTY: 6  BOLT 1/4"*32mm	8 QTY: 6  SPRING WASHER	9 QTY: 6  FLAT WASHER
10 QTY: 12  FLAT HEAD SCREW Ø6*25mm	11 QTY: 7  HANDLE	12 QTY: 14  BOLT Ø8*12mm
13 QTY: 8  HINGES	14 QTY: 90  Ø7*15mm FLAT HEAD SCREW	15 QTY: 7  HINGES
16 QTY: 12  SHELF PIN	17 QTY: 8  Ø7*15mm ROUND HEAD SCREW	18 QTY: 4  CASTER
19 QTY: 6  Ø8*25mm FLAT HEAD SCREW	20 QTY: 1  CAMTOOL	
21 QTY: 1  ALLEN KEY	22 QTY: 2  SPING BALL LATCH	23 QTY: 16  Ø1/4*12mm BOLT

Using Camlocks


Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note：ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.




Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.


Las diapositivas deben separarse antes del montaje.
Después de la separación,déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation,mettez de cŏté jusqu'au moment de l'assemblage.


Pay attention when connecting !
The sliding module must be at the front end.




STEP 1 : Extend Slide
Extender la diapositiva



STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier




Push lever for the left of drawer ,
press the lever for the right of drawer.




STEP 3: Remove Runner
Quitar el corredor
Enever le coureur

Assembly Instructions

Tool required


















Phillips screw driver
(medium & large)







Assembly Instructions

BOX 1 : N707P404588

C_L 	C_R 	F 
LEFT FRAME QTY: 1	RIGHT FRAME QTY: 1	FRONT PANEL - LEFT QTY: 1
G 	H 	I 
FRONT PANEL - RIGHT QTY: 1	FRONT PANEL - MIDDLE QTY: 1	BRACKET - LEFT QTY: 1
J 	K 	L 
BRACKET - RIGHT QTY: 1	BRACKET - LEFT QTY: 1	BRACKET - RIGHT QTY: 1
M 	P 	Q 
BRACKET BOTTOM QTY: 1	MIDDLE SHELF QTY: 1	LEFT/RIGHT SHELF QTY: 2
S 	T 	V 
DRAWER FRONT QTY: 1	DRAWER BACK QTY: 1	DRAWER FRONT QTY: 2














Assembly Instructions

BOX 1 : N707P404588

Y_L 	Y_R 	AA 
DRAWER LEFT QTY: 3	DRAWER RIGHT QTY: 3	EXTENDED SUPPORT QTY: 1
BB 		
EXTENDED SUPPORT QTY: 1		


Assembly Instructions


BOX 2 : N707P404589

A 	B 	DL 
TOP PANEL QTY: 1	EXTENDED TOP PANEL QTY: 1	CENTER PANEL - LEFT QTY: 1
DR 	E 	N 
CENTER PANEL - RIGHT QTY: 1	BOTTOM PANEL QTY: 1	PULL BAR QTY: 4
O 	RL 	RR 
BACK PANEL QTY: 1	LEFT DOOR QTY: 2	RIGHT DOOR QTY: 2
U 	W 	X 
DRAWER BOTTOM QTY: 1	DRAWER BACK QTY: 2	DRAWER BOTTOM QTY: 2
Z 		
DOOR STOP QTY: 3		

Assembly Instructions

STEP 1






1		2PCS
4		2PCS
6		6PCS


Assembly Instructions

STEP 2



1		2PCS
4		2PCS
6		6PCS


STEP 3




1		2PCS
4		2PCS
6		6PCS

Assembly Instructions

STEP 4






2		6PCS
3		6PCS
19		6PCS
20		1PC


Assembly Instructions

STEP 5



1		8PCS
3		8PCS
18		4PCS
21		1PC
23		16PCS


STEP 6



2		8PCS
20		1PC


Assembly Instructions

STEP 7



1		2PCS		8		6PCS
2		2PCS		9		6PCS
7		6PCS		20		1PC
3		6PCS	17		8PCS	21		1PC


STEP 8



1		8PCS
2		8PCS
3		8PCS
20		1PC


Assembly Instructions

STEP 9




5		6PCS
6		18PCS


STEP 10



1		12PCS

STEP 11







2		8PCS
10		8PCS
11		2PCS
12		4PCS

X2

STEP 12







2		4PCS
10		4PCS
11		1PCS
12		2PCS

Assembly Instructions

STEP 13




STEP 14



16		12PCS


STEP 15



11		4PCS
12		8PCS
13		8PCS
14		48PCS


Assembly Instructions

STEP 16



14		24PCS
15		4PCS
22		2PCS


STEP 17




14		18PCS
15		3PCS

Assembly Instructions

Finish!




HINGE ADJUSTMENTS




1 Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from the side of the cabinet
anticlockwise to move the door closer to the side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the screws
clockwise to move the door up
anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw
clockwise to decrease the gap between the door and the cabinet
anticlockwise to increase the gap between the door and the cabinet

