

If there are any missing parts, damaged packaging or broken panels,
please contact our service email for assistance:


furni-service@outlook.com

CONTACT US!

Do Not return this product

If you encounter any missing parts, damaged packaging, or broken panels, please contact our customer service team for assistance:

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④























WhatsApp

For faster resolution:


① Include your **order number** ② Attach **clear photos** of the issue



We appreciate your patience and cooperation, and we'll do our best to resolve your concern promptly. Thank you!





<p>A</p>  <p>52+2PCS</p>	<p>B</p>  <p>52+2PCS</p>	<p>C</p>  <p>Ø6*30MM 28+2PCS</p>	<p>D</p>  <p>2PCS</p>
<p>E</p>  <p>4PCS</p>	<p>F</p>  <p>M4*30MM 14+1PCS</p>	<p>G</p>  <p>48+2PCS</p>	<p>H</p>  <p>M3*16MM 52+2PCS</p>
<p>I</p>  <p>2PCS</p>	<p>J</p>  <p>Ø4*35MM 2PCS</p>	<p>K</p>  <p>2PCS</p>	<p>L</p>  <p>Ø4*12MM 2PCS</p>
<p>M</p>  <p>12PCS</p>	<p>N</p>  <p>M3*12MM 4+1PCS</p>	<p>O</p>  <p>M4*20MM 8+1PCS</p>	<p>P</p>  <p>4PCS</p>
<p>Q</p>  <p>8PCS</p>	<p>R</p>  <p>M4*12MM 48+2PCS</p>	<p>S</p>  <p>8+1PCS</p>	

STEP 1






	A*24PCS		C*18PCS
---	---------	---	---------



STEP 2






STEP 3





STEP 4






STEP 5




STEP 6




STEP 7




STEP 8





	B*6PCS
---	--------

STEP 9




STEP 10





	B*6PCS
---	--------


STEP 11




STEP 12






STEP 13




STEP 14





	B*6PCS		M*6PCS
---	--------	---	--------







STEP 15





	I*2PCS		L*2PCS
---	--------	---	--------

STEP 16









	A*6PCS		D*2PCS		H*4PCS
---	--------	---	--------	---	--------

STEP 17





Please flip it 180°





	A*22PCS		C*10PCS
---	---------	---	---------



STEP 18





STEP 19




STEP 20





STEP 21





STEP 22




STEP 23




STEP 24



STEP 25




STEP 27



	G*48PCS		H*48PCS
--	---------	--	---------


STEP 28



	P*2PCS		Q*4PCS		R*8PCS
	E*2PCS		N*2PCS		O*4PCS

X2



STEP 29





	P*2PCS		Q*4PCS		R*8PCS
	E*2PCS		N*2PCS		O*4PCS

X2



STEP 30








STEP 31



STEP 32





	J*2PCS		K*2PCS
---	--------	---	--------





To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.

Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.

THANK YOU!

Contact our friendly
customer service team first for help

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④



WhatsApp

If you have any questions, please leave the **order No.**
and **related picture** information, we will reply you
within 24 hours, and solve the problem as soon as possible.