

































ASSEMBLY INSTRUCTIONS





PARTS AND HARDWARE




Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.











	(A)x1		(B)x1		(C)x1
	(D)x1		(J)x1		(K)x1
	(Q)x12		(R)x1		





Do not fully tighten bolts until assembly is complete.












Do not fully tighten bolts until assembly is complete.

 (H)x1	 (G)x1	 (I)x1
 (D)x1	 (J)x1	 (K)x1
 (Q)x12	 (R)x1	










Do not fully tighten bolts until assembly is complete.

 (E)x2	 (F)x2	 (D)x4
 (J)x2	 (K)x2	 (Q)x20
 (R)x1		





Repeat the above steps to assemble the other middle sofa.
Do not fully tighten bolts until assembly is complete.

 (M)x1	 (N)x2	 (O)x2
 (P)x1	 (Q)x12	 (R)x1



Do not fully tighten bolts until assembly is complete.



Do not fully tighten bolts until assembly is complete.