


YS-11

JSVN-TC501-X-0
JSVN-RBTC-X-0



Instruction Manual!

Thank you for shopping with us!

If any parts is missing, broken upon receipt or you need any help from us.

For the FASTEST solutions, please FIRSTLY CONTACT US at our

after-sales email: **CSsince1987@hotmail.com!**



1. ASSEMBLY PREPARATION AND TIPS FOR ASSEMBLY

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly. Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.
4. Allow ample room for assembly and assemble the product near where the product will be placed.
5. During assembly, do not over-tighten any fittings as this may cause damage.
6. Always place the product on a flat, level surface






2. MAINTANANCE

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
3. Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.

3. DAILY CARE

1. Avoid placing your furniture in direct sunlight, as sunlight causes fading.
2. Use a protective pad when writing on the furniture surface.
3. Use cutting boards and trivets for food preparation in order to avoid damaging the top for the unit


Exploded View



I



J



I




J




E




F



G



H




K

Parts List




A




Left seat frame

B




Right seat frame

C



Coffee Table Board(1)

D



Armrest bag(2)

Hardware list

E



M5x95x35Wrench (1)

F



16mmGasket (4)

G



8x22 Screw(4)

H



70x25x3 Foot plate(2)

I



Middle foot of sofa(4)

J



Sofa foot(2)


K



8*50Screw(6)



Step 1

Get all the hidden parts out of A and B









Step 2

Install the sofa leg J into the hole at the lower left corner of the seat frame A, and then install the sofa foot I into the hole at the upper left corner of the seat frame A








Step 3

Install the sofa leg J into the hole at the lower right corner of the seat frame B, and then install the sofa foot I into the hole at the upper right corner of the seat frame B



Step 4






Connect the upper and lower two holes of the A and B seat frames without sofa legs with an iron sheet H and a screw G, and then install the sofa legs I onto the iron sheet H





Step 5

Lift up the backrest and insert the coffee table.
Fix with screws and stick on Velcr




Step 6

DX2




Put the armrest bag on the sofa




Step 7


Put down the coffee table and the assembly is finished



Step 7




Angle One
 105°



Angle Two
 135°

Tip:

Pull the backrest forward till you hear the snap sound and push it backwards slowly to the angle you want.



Angle Three
 180°

Warning

Seller is responsible for the product-related issues occurred upon receipt, but will not be responsible for the personal injury, property damage or loss resulting from the incorrect assembly, improper use, inadequate maintenance or neglect of this product.