




Please keep children away from the plastic bags

Fully Recover Need At Least


72 hours



Open and remove



Cut the PE film




Resumption

Compressed sofas

Part 1: Unboxing Instructions

Unbox Carefully: Use scissors to cut the sealed bag along the edge of the bag being careful not to cut the sofa body, then remove the bag and take the sofa out of the sealed bag. The sofa will expand rapidly.




Patting wrinkles: Due to package compression for better shipment, the fabric may have wrinkles. Please take all packages out and pat every part to make it rebound better and fluffy. If the fabric cover still has wrinkles, Use a steam ironing machine to iron it.



Part 2: Helpful tips

Stable cushion: Sofa with removable seat cushion, Remove the fabric strip from the back of the seat cushion to allow the Velcro and magic cloth to adhere.



Recovery assistance: The matching sofa cushion, once unpacked, Can be repeatedly patted after being flattened, make it rebound better and fluffy.

