

ASSEMBLY INSTRUCTIONS

VERY IMPORTANT □

PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS. NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY.

Carefully unpack this lamp and place it on a flat surface.

1. Attach the dented washer (4), metal washer (3), spring washer (2) onto screw (1) then attach it through the Weight-base (5), base cover (6), cover (7) to connect the pole (9), tighten using tool.(tool included).
2. Connect the junction boxes (8) together and connect pole (9), (10) then lock it with screw (11) using screwdriver. (Screwdriver not included)
3. Attach the shades (12) onto sockets and secure it with rings (13).
4. Install the bulbs (14) into socket.

Use 3 pcs 60W (Maximum) Incandescent A Type Bulb or LED 3 pcs 9W Type Bulb

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

ATTENTION:

POUR PRÉVENIR LES CHOC ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DECOURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES A FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

※ **PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**

※ **SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

