Instruction Manual

SIDE TABLE FLOOR LAMP

Questions?

E-mail our customer service department at customerservice@alltherages.com

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock and fire, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this safety feature.

This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids. Never cover the lamp with any object including cloth or paper as this is a fire hazard. Do not handle the bulb immediately after the light is turned off as it will be hot. This is not a toy.



Preparation

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and diagram. If any part is missing or damaged, do not attempt to assemble product. Contact customer service for replacement parts. Estimated Assembly Time: 20 minutes

CONTENTS

DESCRIPTION	QUANTITY
Floor Board	1
Shelf Board	1
Top Board	1
Shade	1
Screws	8
Socket Nut	1

LIMITED WARRANTY

All the Rages Inc, a New Jersey corporation, having its principal place of business at 355 Eisenhower Parkway Livingston, NJ 07039 (All the Rages) warrants its products (the "products") as follows:

1. Limited Warranty.

Manufacturer warrants that the products sold hereunder will be free from defects in material and workmanship for a period of one (1) year from the date of purchase. If the products do not conform to this Limited Warranty during the warranty period (as herein above specified), Buyer shall notify Manufacturer in writing of the claimed defects and demonstrate to Manufacturer's satisfaction that said defects are covered by this Limited Warranty. If the defects and proof of purchase are properly reported to Manufacturer within the warranty period, and the defects are of such type and nature as to be covered by this warranty, Manufacturer shall, as its own expense, furnish replacement products or, at Manufacturer's option, replacement parts for the defective products. Installation of the replacement products or replacement parts shall be at Buyer's expense.

2. Exclusive Obligation:

THIS WARRANTY IS EXCLUSIVE. The sole and exclusive obligation of Manufacturer shall be to repair or replace the defective products in the manner and for the period provided above. Manufacturer shall not have any other obligation with respect to the products or any part thereof, whether based on contract, tort, strict liability or otherwise. Under no circumstances, whether based on this Limited Warranty or otherwise, shall Manufacturer be liable for incidental, special, or consequential damages.

3. Other Statements.

Manufacturer's employees or representatives' oral or other written statements do not constitute warranties, shall not be relied upon by Buyer, and are not part of the contract for sale or this limited warranty.

4. Entire Obligation.

This Limited Warranty states the entire obligation of Manufacturer with respects to the products. If any part of this Limited Warranty is determined to be void or illegal, the remainder shall remain in full force and effect.



ALL THE RAGES INC
355 EISENHOWER PARKWAY
LIVINGSTON, NJ 07039
WWW.ALLTHERAGES.COM
PRINTED IN CHINA

ASSEMBLY INSTRUCTIONS:

slats on each leg.

Step 1: Insert 4 screws at the bottom of the floor board.

Step 2: Attach the 4 legs onto the screws on the floor board and tighten, making sure that the cut out slats on each leg face inward. STEP 3: Insert the shelf board into the cut out

STEP 4:Place top board on top of the legs, making sure the wooden pieces underneath the top board line up in between the sides of the legs and tighten on each side with the remaining 4 screws.


Step 5: Insert the curved socket pole onto the straight pole and tighten.

STEP 6:Insert the straight pole into designated hole on top board, from the underside of the top board push the washer up to the pole you just inserted and tighten the nut securing the pole into place.

Step 7: Remove the socket nut from the socket, remove the plastic from the shade and attach the shade by putting the shade on the socket and tightening the shade into place with the socket nut.

Step 8: Plug the electrical supply cord into the wall outlet. Use the pull chain located on the socket to turn the lamp on/off.

*Note: Additional outlet/USB ports are not a standalone power source. Lamp must be plugged in for power to be provided to this outlet.



CLEANING & MAINTENANCE:

- 1. Unplug the fixture before cleaning.
- Use a clean, dry, soft, lint-free cloth.
 Do not use water or other chemical cleaning agents.

2

included)