


ASSEMBLY INSTRUCTION

ITEM: N715P491303


DINING CHAIR







IMPORTANT NOTE :


- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP

Detail view




Part List For One Chair		Hardware List For One Chair	
A  Backrest (1pc)		1  Ø1/4" x 75mm Bolt (4pcs)	
		2  Ø1/4" x 35mm Bolt (2pcs)	
B  Right Front Leg (1pc)		3  Ø1/4" x 13mm x 1.5mm Spring Washer (6pcs)	
		4  Ø1/4" x 16mm x 1.5mm Flat Washer (6pcs)	
C  Left Front Leg (1pc)		5  Ø5/16" x 6mm Hex nut (4pcs)	
		6  Ø5/16" x 16mm x 1.5mm Flat Washer (4pcs)	
D  Seat Frame (1pc)		7  90 x 12mm Open wrench (1pc)	
		8  4 x 58mm Allen key (1pc)	

Step 1





2	Ø1/4"x35		2PCS	4	Ø1/4"x16x1.5		2PCS
3	Ø1/4"x13x1.5		2PCS	8	4x58		1PC

Step 2



1	Ø1/4"x75		4PCS	4	Ø1/4"x16x1.5		4PCS
3	Ø1/4"x13x1.5		4PCS	8	4x58		1PC

Step 3



Completed

5	Ø5/16" x 6mm		4PCS				
6	Ø5/16"x16x1.5		4PCS	7	90 x 12mm		1PC