

DOOR REVERSAL INSTRUCTIONS

If the appliance is placed on its back or side for any length of time during this process, it must be allowed to remain upright for 6 hours before plugging it in to avoid damage to the internal components.

The process of replacing the reversible door is divided into the following six steps, as shown below:

1. Use a knife to remove the three screw hole covers from the upper left hinge and lower left hinge of the fridge, respectively. (Step 1)
2. Use a knife to remove the decorative cover on the door, then use a hex screwdriver to remove two screws from the lower right hinge. Slide the bottom of the door outward to detach it from the casing. (Step 2).
3. Use a screwdriver to remove three screws from the upper right hinge and detach the upper right hinge. Then, remove three screws from the lower right hinge and detach the lower right hinge. (Step 3)
4. Use a screwdriver to secure the upper left hinge and the lower left hinge separately with screws. (Step 4)
5. Remove the door handle, install it on the right side of the door, and then insert the removed decorative cover into the upper right corner hole. (Step 5)
6. Install the door on the left side of the fridge. Slide the door onto the top left corner hinge, then replace the door axis by placing the hinge pin at the bottom of the door and securing it to the lower left hinge with two screws using a hex screwdriver. Ensure that the top of the door is properly aligned with the top of the fridge, that the actuator makes contact with the switch on the chassis, and that the rubber gasket creates a tight seal with the cabinet all the way around. (Step 6)

TITTLA ' s customer service will guide you through the whole service procedure regarding any product issues or problems you have encountered.

Contact Card

Web: www.tittla.com

E-mail: Support@tittla.com

Phone: 1(510)228-4672

1. Knife
2. Hole cover
3. Decorative cove
4. Hex screwdriver
5. Hex screw
6. Upper right hinge
7. Lower right hinge
8. Screwdriver
9. Upper left hinge
10. Lower left hinge
11. Door handle

